


CUMSA

INNOVATIVE SOLUTIONS
FOR YOUR MOLDS



1 SLIDES



2 UNDERCUTS



3 EJECTION



4 TRACEABILITY



5 VACUUM



6 ACCESSORIES



A written history, but still with a long way to go

CUMSA was founded by Mr. Alberto Navarra in 1979, when, in association with a small group of Spanish toolmakers, decided to combine their knowledge and create the company.

Their objective was to develop mold projects from the initial stages of design through the serial plastic parts production.

From the early beginning, the company was focused on expanding its operations outside of Spain. Consequently, they first reached out to Mexico, Denmark, and the USA.

In 1992 CUMSA decided to make a 180° turn, took advantage of Mr. Alberto Navarra deep knowledge of the tooling industry, and started to create an innovative range of standard components for molds.

Since then, many products have become a reference standard in the mold making industry due to their simplicity in functionality as well as easy assembling and adjusting. All the products are designed as a result of a deep R+D process, keeping in mind the challenges that designers, mold-makers and molders have to deal with.

Nowadays, CUMSA continues as a family owned and operated company, headquartered in Barcelona, Spain, with subsidiaries in the USA, Portugal, Italy, and China, focused on the design, manufacturing and distribution of innovative standard components for the mold making and molding industries.

Alone we can do so little, together we can do so much

CUMSA values are how we believe a company should be. A place where every single worker is an essential part of the process to achieve the objectives as a team.

Each letter of CUMSA name represents our 5 TOP values:

C for **Creativity**, to go one step ahead.

U for **Unity**, because by moving forward together we go further.

M for **Motivation**, which provides us with optimism, positive energy, flexibility and agility.

S for excellent **Service** to our stakeholders.

A for an open and detail-oriented **Attitude**.



SOLUTIONS
MOLDS



Globalization is our DNA

CUMSA has focused since its beginnings in exporting their products worldwide, this gives the chance to grow as a company, discover new problems, and find how to solve them in different ways.

Actually, CUMSA has a distribution network over 45 different countries, and also direct selling from the headquarters to Spain and Germany, and as well as to other countries where non CUMSA official dealer is present.

So every single toolmaker or molder in the world can obtain the benefits that CUMSA products offer.

CUMSA have its own subsidiaries in strategic areas around the world:

EURO CUMSA —
In Marinha Grande area (Portugal), established in 1998.

CUMSA —
— ITALIA —
In Milano area (Italy), established in 2004.

CUMSA —
— 坤盛 中国 —
In Shenzhen (China) and Hong Kong, established in 2009.

CUMSA —
— USA —
In Troy (Michigan-USA), established in 2012.

But not only CUMSA grows in commercialization, because by the end of 2017, a new production plant was built in Portugal. There, we manufacture hydraulic cylinders specially designed for the mold making industry, and also some components included in this catalogue.

CUMSA
—TECH—

Quality is not an act, it is a habit

We are committed to the development of effective products and services. Since 1997, CUMSA is certified by a Quality Management System according to the ISO-9001 standards, which is annually audited by the international leading company Det Norske Veritas AS who verifies that all processes meet the standard requirements.

At CUMSA the four 4 main areas of the quality management system are applied to:

- Continuous investment in new IT technologies, production, and testing systems, as well as in new machines to optimize all the processes.
- Quality control through all stages of the production process until the product is delivered to the customer.
- Continuous employee training to increase knowledge and quality awareness regarding services and products.
- Fast and valuable answers to customer's needs, to help them to achieve their requirements.



ALPHABETICAL INDEX

SECTION INDEX

ACCESSORIES	152-153
EJECTION.....	80-81
SLIDES	20-21
TRACEABILITY.....	108-109
UNDERCUTS	46-47
VACUUM	126-127

PRODUCT INDEX

A

AE Accelerated Ejector	99
AL Threaded Limiter Adapter.....	100
AP Sprung Core Extension	67
AS Automatic Safety Strap.....	158

B

BA Ejector Base	102
BC Slide Base	35
BD Horiz. & Adaptable Base	74
BE Ejector Base	102
BG Angle Pin Housing	37
BI Interchangeable Insert	114
BM Block Base	121
BR Water Connector	161
BT Ejector Base	102

C

CA Adjusted Slide	34
CC Cycle Counter	122
CF Remote D. Stamp Shaft SET	110
CG Heel Unit - SET	34
CG Heel Unit.....	33

CI Angled Guide Bush	76
CK 90° Plate Connector	58
CP Full Color Plaque	167
CS Compact Slide	28
CR Cooled Compact Slide.....	30
CT Shaft Couting Jig	112
CV Vacuumjet Plug	146
CX PX Cutting Jig	69

D

DE Double Ejection	91
DF Fixed Lifter Base	75
DG Dog Lifter - DG	73
DK DR Cooling Hose	52
DL Dog Lifter - DL	72
DP Ejector Foot	104
DR Double Rack Lifter	50
DX Superior Double Ejector	86
DY Rear Double Ejector	92

E

EB EX-EY-EZ External Fixing ...	98
EC Sprue Bushing Hardened.....	162
ED Double Ejector	70
EE Tulip Ejector	71
EF Removal Jig	117
EP Plate Accelerator	90
EW EX-EY-EZ Rod Extension ...	98
EX Ext. Sup. Plate Separator	88
EY External Double Ejection	94
EZ External Synchronized Plates ..	96

F

FA Date Stamp	116
FC KR Cooling Hose	57
FD Double Date Stamp	119
FP Date Stamp Plus	117
FR Remote Date Stamp	110
FT Temperature Dater	120
FU Unit Date Stamp	115
FV Filter Valve	154
FX Xtra Date Stamp	118

G

GI Angle Pin	36
GR Angle Pin Housing	36
GS Latch Lock	84

I

IA Date Insert	116
IG Turning Insert	114
II Interchangeable Insert	114
IM Mark Insert	113
IR Recycling Insert	113
IT Temperature Insert	120
IU Unit Date Stamp	115
IX Xtra Insert	118

J

JR Seal Bearing	163
JV Vacuumjet Seal	148

K

KR Cooled Rack Lifter	56
-----------------------------	----

L

LD Dog Lifter Limiter	101
LR Threaded Limiter	100
LV Laminar Gas Vent	147

M

MB Mini Base	25
MC Mini Slide	24
MG Mini Guide	24
MK Connection Hose	58
MN Remote Command	110
MR Cooling Hose	32
MS Mini Slide	22
MX Internal Latch Lock	85

N

NP Non-rotating Head Ej. Pins	144
NR Keyed Tubular Base	145

P

PA Pneumatic Piston	143
PF Flexible Core	64
PH Ejectors	146
PI Identification Plate	166
PM Block Insert	121
PO Optional Dowel Pin	40
PR Plate Retainer	82
PS Standard Lifter	65
PT Pneumatic Piston	143
PW Sprung Core	66
PX Xtra Sprung Core	68

R

RA Automatic Retainer	42
RC Slide Retainer	40
RCM Slide Retainer	41
RD Cooling Distributor	58
RF Adjustable Fixing	53
RL Cooling Connector	161
RM Modular Retainer	83
RR Interchangeable Wheel	169

S

SA Sprue Adjuster	157
SB Seal Bearing	164
SC Cable Retainer	168
SD Undercut Base Unit	76
SE Stroke Limiter	82
SM Hose Retainer	168
SPECIAL Special Sprung Core ..	77
SU Slide Unit	26
SV Smart Vacuumjet	134
SX Superior Plate Separator ..	87
SY Compact Double Ejection ..	93

T

TA Shock Absorber	105
TB Seal Bearing Tube	165
TE Headless Sleeve Ejector ...	103
TH Extension Tube	160
TK Turning Key	112
TL Brass Pipe	165
TM Safety Stopper	104

U

UA Compact Coring Unit	39
UC Core Cam	38
UM Marking Unit	169
UU Undercut Unit	27

V

VA Air Valve	154
VB Double Action Vacuum	132
VD Double Valve	156
VE Headless Ejector Pin	103
VG Vacuumjet +	138
VH High Pressure Air Valve ...	155
VI Lifter Shaft	75
VJ Vacuumjet Unit	136
VM Vacuum Control	140
VP Spiral Ejector	144
VS Spiral Sleeve	145
VT Vacuumjet Valve Tube	142
VV Vacuumjet Valve	142



W

WF WP Adjustable Fixing	63
WL Smart Worm Lifter	60
WP Smart Worm Pin	62

X



XR Xtreme Double Rack	54
-----------------------------	----

GRAPHIC INDEX





GRAPHIC INDEX



LD
101

CATALOGUE

GUIDELINES

WEBSITE

GUIDELINES

Temperature / Pressure

Correct / Not Correct

Screw / Unscrew

Replace

360°

Assembly

Cut

Drill

Air

Seal

Surface Roughness (Rz)

Grind

Not included

Thread

Max. Torque:

Metric	M4	M5	M6	M8	M10	M12	M14	M16	M18	M20	M22	M24
Torque	3	6	10	25	54	92	145	230	325	460	630	790

Website Icons

3D Step ↓

3D Group ↓

False Cut ↓

Catalogue ↓

Instructions

Spare Parts ↓

Video ↓

Important information:

- All the product information can be found in this catalogue, but the latest and most updated information can be found at [cumsa.com](https://www.cumsa.com)
- The catalogue in the website is interactive, this means that you can navigate quickly between the pages / categories, clicking on links (indexes, categories on the bottom of the page, QR's and product indications)

1

SLIDES

CUMSA
CS.423009
23101704

CUMSA
CS.423017
23101704

SLIDES INDEX

ÍNDICE CORREDERAS / INHALTSVERZEICHNIS SCHIEBER
INDICE CORSA / ÍNDICE CORREDIÇAS / INDEX CHARIOTS

22/

Mini Slide
Mini Corredera
Mini Schieber
Carrello Mini
Mini Corrediça
Mini Coulisseau



34/

Heel Unit - SET
Cuña Guía-SET
Keilführungs-SET
Contrasto Guida-SET
Guia Cunha-SET
Guide de Chariot-SET



34/

Adjusted Slide
Corredera Ajustada
Vorabgestimmter Schieber
Carrello Aggiustato
Corrediça Ajustada
Coulisseau de Chariot



35

Slide Base
Base Corredera
Basisführung
Base Carrello
Base da Corrediça
Embase Coulisseau



24/

Mini Guide
Mini Guia
Mini Schieberführung
Mini Guida
Mini Guia
Mini Guide



24/

Mini Slide
Mini Corredera
Mini Schieber
Mini Carrello
Mini Corrediça
Mini Coulisseau



25/

Mini Base
Mini Base
Mini Basis
Mini Carrello
Mini Base
Mini Base
Mini Base



36/

Angle Pin Housing
Guia Regulable
Schrägstiftbuchse
Bussola Regolabile
Guia Regulável
Guidage de Verrouillage



36/

Angle Pin
Guia Inclínada
Schrägstift
Colonna Inclínada
Guia Inclínada
Doigt de Demoulage



37/

Angle Pin Housing
Base Guia
Schrägstiftbuchse
Base Portacolonna
Porta Guias
Socle de Guidage



26/

Slide Unit
Conjunto de Corredera
Schieber Einheit
Gruppo Carrello
Elemento Móvel
Chariot



27/

Undercut Unit
Corredera para Negativos
Verdeckte Schieber
Carrello per Sottosquadra
Elemento Móvel Interior
Chariot Intérieur



38/

Core Cam
Unidad de Punzonado
Kernstifthalter
Unità di Punzonatura
Unidade de Furação
Guide Broche



39/

Compact Coring Unit
Unidad Apriete
Kompakt Kernstifthalter
Unità Compatta di Punzonatura
Unidade de Aperto
Butée de Broche



28/

Compact Slide
Corredera Compacta
Kompakt Schieber
Carrello Compatto
Corrediça Compacta
Compact Coulisseau



30/

Cooled Compact Slide
Corredera Compacta Refrigerada
Gekühlter Kompakt Schieber
Carrello Compatto con Refrigerazione
Corrediça Compacta Refrigerado
Compact Coulisseau Réfrigéré



40/

Slide Retainer
Retensor Corredera
Schiebersicherung
Ritenore Carrello
Retensor de Corrediças
Blocage de Coulisseau



40/

Optional Dowel Pin
Pasador Opcional
Zylinderstift (Optional)
Riferimento Opzionale
Cavilha Opcional
Goupille Optionnel



41/

Slide Retainer
Retensor Corredera
Schiebersicherung
Ritenore Carrello
Retensor de Corrediças
Blocage de Coulisseau



32/

Cooling hose
Refrigeración CR
Kühlungsschlauch für CR
Refrigerazione CR
Refrigeração CR
Refroidissement CR



33/

Heel Unit
Cuña Guía
Keilführungs
Contrasto Guida
Guia Cunha
Base de Verrouillage



42/

Automatic Retainer
Retensor Automático
Zuhaltung, Automatisch
Ritenore Automatico
Retensor Automático
Retenue Automatique



MS

SLIDES



Patented


Max. 150°C



MINI SLIDE

ES Mini Corredera DE Mini Schieber
IT Carrello Mini PT Mini Corrediça FR Mini Coulisseau


● Cad Insertion Point



Ref.	A	B	C	D	E	F	G	H	J	K	L	M	N	R	Stroke	T	T2	U	V	W	X	Z	SWa
MS.121503	12	24	12	11.6	12.2	15	12.5	18.5	28	19.5	10	16	5	3	3	M5x20	M5x20	12	20	12.5	4	4.5	3
MS.182006	18	41	16	17.6	16.5	20	16.5	22.5	47	32.5	16	28	4.5	5	6	M6x40	M5x25	12	26	15.5	7	13	4
MS.242608	24	45	20	23.6	20.5	26	16.5	26.5	53	38.5	16	28	4.5	5	8	M6x45	M5x25	17	30	16.5	7	15	4

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



Core Housing

Alojamiento Placa Punzón · Einbaumaße PB Führung · Sede nel Punzone · Alojamento Bucha · Logement dans l'empreinte




Cavity Housing

Alojamiento Placa Cavidad · Einbaumaße DR Führung · Sede piastra cavità · Alojamento na Cavidade · Logement dans l'empreinte




Core Slide Installation

Instalación Placa Punzón · Einbaumaße DR Führung · Installazione piastra punzone · Alojamento na Bucha · Logement dans l'empreinte



Cavity Slide Installation

Instalación Placa Cavidad · Einbaumaße DR Führung · Installazione piastra cavità · Instalação da corrediça no lado da cavidade · Logement dans l'empreinte



MS

SLIDES

Patented


Max. 150°C



MG



Patented
 Max. 150°C



MINI GUIDE

ES Mini Guia DE Mini Schieberführung
 IT Mini Guida PT Mini Guia FR Mini Guide

● Cad Insertion Point


Ref.	A	CR (N)
MG.121648	12	50.000
MG.201648	20	90.000

IMPORTANT !
 Standard stroke of 4mm.
 Recorrido estándar de 4mm.
 Standard Hub 4mm.
 Corsa carrello 4mm.
 Curso standard de 4mm.
 Course standard de 4mm.

MC




Patented
 Max. 150°C




MINI SLIDE

ES Mini Corredera DE Mini Schieber
 IT Mini Carrello PT Mini Corrediça FR Mini Coulisseau

● Cad Insertion Point




Ref.	A	B
MC.121252	12.5	12
MC.121652	12.5	16
MC.201252	20.5	12
MC.201652	20.5	16




MINI BASE

ES Mini Base DE Mini Basis
 IT Mini Base PT Mini Base FR Mini Base

● Cad Insertion Point



Ref.	A	B
MB.122056	12.5	28
MB.202056	20.5	36



MB




Patented
 Max. 150°C


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Mold Open



Mold Closed



IMPORTANT !
 Max. 0.6

SU

SLIDE UNIT

ES Conjunto de Corredera DE Schieber Einheit
IT Gruppo Carrello PT Elemento Móvel FR Chariot

UNDERCUT UNIT

ES Corredera para Negativos DE Verdeckte Schieber
IT Carrello per Sottosquadra PT Elemento Móvel Interior FR Chariot Intérieur


UU

Patented

Max. 150°C

Patented



Max. 150°C



Ref.	A	B	C	D	E	F	H	K	L	M	R	S	T	X	SW
SU.081220	8.2	12	20	10	18	28	32	12.5	8.25	8	3.75	3	M4	6.2	2.5
SU.121626	12.2	16	26	12	24	37.5	36	17	10.5	11	4.5	4	M5	7.2	3
SU.162032	16.2	20	32	16	30	46.5	40	22	13	14	5	5	M6	9.2	4

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Ref.	A	B	C	D	E	F	G	H	J	K	L	M	R	S	T	X	SW
UU.081220	8.2	12	20	10	18	24.5	12	32	16	12.5	8.25	8	3.75	3	M4	6.2	2.5
UU.121626	12.2	16	26	12	24	32.5	16	36	20	17	10.5	11	4.5	4	M5	7.2	3
UU.162032	16.2	20	32	16	30	41	20	50	25	22	13	14	5	5	M6	9.2	4

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



CS

SLIDES







Patented

Max. 150°C

COMPACT SLIDE

ES Corredera Compacta DE Kompakt Schieber
IT Carrello Compatto PT Corrediça Compacta FR Compact Coulisseau


● Cad Insertion Point



Ref.	A	B	C	D	E	F	H	J	K	P	Q	N	Stroke	T	U	V	W	Z
CS.423009	42	50	26	41.5	24	30	32.5	60	54	-	-	-	9	55	32	30	24	20
CS.423017	42	50	26	41.5	24	30	32.5	68.5	62.5	17	34	12	17	55	32	30	24	20
CS.523511	52	56	32	51.5	30	35	38.5	69	63	-	-	-	11.5	55	38	34	26	20
CS.523519	52	56	32	51.5	30	35	38.5	76	70	20	35	9	19	55	38	34	26	20
CS.624014	62	62	38	61.5	36	40	44.5	77	72	-	-	-	14	60	44	38	28	24
CS.624022	62	62	38	61.5	36	40	44.5	85	81	23	39	11	22	60	44	38	28	24

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



CS


SLIDES

Patented

Max. 150°C



Core Housing

Alojamiento Placa Punzón · Einbaumaße PB Führung · Sede nel Punzone · Alojamento Bucha · Logement dans l'empreinte




Cavity Housing

Alojamiento Placa Cavidad · Einbaumaße DR Führung · Sede piastra cavità · Alojamento na Cavidade · Logement dans l'empreinte




Core Slide Installation

Instalación Placa Punzón · Einbaumaße DR Führung · Installazione piastra punzone · Alojamento na Bucha · Logement dans l'empreinte



Cavity Slide Installation

Instalación Placa Cavidad · Einbaumaße DR Führung · Installazione piastra cavità · Instalação da corrediça no lado da cavidade · Logement dans l'empreinte



PLAY

COOLED COMPACT SLIDE

ES Corredera Compacta Refrigerada DE Gekühlter Kompakt Schieber
 IT Carrello Compatto con Refrigerazione PT Corrediça Compacta Refrigerado FR Compact CoulisseauRéfrigéré


CR

SLIDES




Patented

Max. 150°C




Ref.	A	B	C	D	E	F	G	H	J	K	P	Q	N	Stroke	T	U	V	W	X	Z
CR.424509	42	50	26	41.5	24	45	17	32.5	60	54	-	-	-	9	55	32	30	24	50	20
CR.424517	42	50	26	41.5	24	45	17	32.5	68.5	62.5	17	34	12	17	55	32	30	24	50	20
CR.525011	52	56	32	51.5	30	50	23	38.5	69	63	-	-	-	11.5	55	38	34	26	55	20
CR.525019	52	56	32	51.5	30	50	23	38.5	76	70	20	35	9	19	55	38	34	26	55	20
CR.625514	62	62	38	61.5	36	55	29	44.5	77	72	-	-	-	14	60	44	38	28	60	24
CR.625522	62	62	38	61.5	36	55	29	44.5	85	81	23	39	11	22	60	44	38	28	60	24



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation

CR

SLIDES




Patented

Max. 150°C



Core Housing

Alojamiento Placa Punzón · Einbaumaße PB Führung · Sede nel Punzone · Alojamento Bucha · Logement dans l'empreinte




Cavity Housing

Alojamiento Placa Cavidad · Einbaumaße DR Führung · Sede piastra cavità · Alojamento na Cavidade · Logement dans l'empreinte




Core Slide Installation

Instalación Placa Punzón · Einbaumaße DR Führung · Installazione piastra punzone · Alojamento na Bucha · Logement dans l'empreinte



Cavity Slide Installation

Instalación Placa Cavidad · Einbaumaße DR Führung · Installazione piastra cavità · Instalação da corrediça no lado da cavidade · Logement dans l'empreinte



PLAY



PLAY

MR

SLIDES


Patented

Max. 70°C

CR COOLING HOSE

ES Refrigeración CR DE Kühlungsschlauch für CR
IT Refrigerazione CR PT Refrigeração CR FR Refroidissement CR

● Cad Insertion Point




Ref.	L
MR.180500	500
MR.181000	1000


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Cavity Installation




Core Installation



HEEL UNIT

ES Cuña Guía DE Einstellbare Zuhaltung
IT Contrasto Guida PT Guia Cunha FR Base de Verrouillage

● Cad Insertion Point




Ref.	A	B	C	D	E	G	H	K	M	R	T	U	RP	CR (N)	SWa	SWb	SWc
CG.603035	60	30	35	25	23	6	17	29	43.7	17	M6x25	10	081015	180.000	5	3	4
CG.604035	60	40	35	25	23	6	17	29	43.7	22	M6x25	10	101015	320.000	5	4	5
CG.754049	75	40	49	30	32	7	20	39	58	22	M8x30	12	101020	320.000	6	5	5
CG.864857	86	48	57	35	36	8	24	44	65	28	M8x35	16	121025	480.000	6	6	6

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Mold Closed



CG

Patented


Max. 150°C



CG


HEEL UNIT - SET

ES Cuña Guía - SET DE Keilführungs - SET
IT Contrasto Guida - SET PT Guia Cunha - SET FR Guide de Chariot - SET



● Cad Insertion Point


Ref.	A	B	CR (N)	RP	SWa	SWb	SWc	Includes
CG.603075	17	30	180.000	081015	5	3	4	GI.010075
CG.604075	22	40	320.000	101015	5	4	5	GI.010075



IMPORTANT ! Standard stroke of 11mm.
Recorrido estándar de 11mm.
Standard Hub 11mm.
Corsa carrello 11mm.
Course standard 11mm.
Course standard de mmm.

Patented


Max. 150°C



SLIDE BASE

ES Base Corredera DE Basisführung
IT Base Carrello PT Base da Corrediça FR Embase Coulisseau

● Cad Insertion Point




Ref.	A	B	C
BC.322885	32	56	21.5
BC.422885	42	66	26.5

BC

Patented

Max. 150°C






CA

ADJUSTED SLIDE

ES Corredera Ajustada DE Vorabgestimmter Schieber
IT Carrello Aggiustato PT Corrediça Ajustada FR Coulisseau de Chariot

● Cad Insertion Point




IMPORTANT !

Ref.	A	B
CA.322080	32	20
CA.322480	32	24
CA.422080	42	20
CA.422480	42	24

Patented


Max. 150°C




Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Mold Open



Mold Closed




IMPORTANT !
Max. 1



GR

ANGLE PIN HOUSING

ES Guía Regulable DE Schägstiftbuchse
IT Bussola Regolabile PT Guia Regulável FR Guidadge de Verrouillage



Ref.	A	B	C	D	E	F	G	H	S	T	U	X°	SW	
GR.182622-..	18	26	22	12	10.8	7.5	6	3.8	M5x5	M5x16	10	10	15	3
GR.222826-..	22	28	26	16	11	11	6	4	M6x6	M6x16	12	10	15	4
GR.283432-..	28	34	32	16	13	13	6	5	M6x6	M6x16	16	10	15	4
GR.344038-..	34	40	38	20	17	17	8	5.5	M8x6	M8x20	20	10	15	5
GR.424546-..	42	45	46	20	19.5	19.5	8	6	M8x6	M8x20	24	10	15	5
GR.465050-..	46	50	50	20	21	21	8	7	M8x6	M8x20	28	10	15	5

IMPORTANT !
Indicate the desired **X** dimension after the reference.
Indicar al final de la referencia, la cota **X** deseada.
Gewünschte **X** Dimension angeben, nach der Referenznr.
Indicare la quota **X** desiderata alla fine del codice.
Indique o dimensão **X** desejada depois da referência.
Préciser le début de référence et le compléter par la dimension **X** souhaitée.

Patented




Max. 150°C

GI

ANGLE PIN

ES Guía Inclinada DE Schrägstift
IT Colonna Inclinata PT Guia Inclinada FR Doigt de Demoulage



Ref.	A	Adjustment Area	M	N	L	R
Gi.010...	10	≈ 25	4	4	075 090 105	5
Gi.012...	12	≈ 30	4	4	095 110 130	6
Gi.016...	16	≈ 35	4	4	115 135 160	8
Gi.020...	20	≈ 40	6	6	140 165 190	10
Gi.024...	24	≈ 45	6	6	170 195 220	12
Gi.028...	28	≈ 50	6	6	200 225 250	14

IMPORTANT !
Indicate the desired **L** dimension after the reference.
Indicar al final de la referencia, la cota **L** deseada.
Gewünschte **L** Dimension angeben, nach der Referenznr.
Indicare la quota **L** desiderata alla fine del codice.
Indique o dimensão **L** desejada depois da referência.
Préciser le début de référence et le compléter par la dimension **L** souhaitée.



Max. 150°C

ANGLE PIN HOUSING

ES Base Guía DE Schägstiftbuchse
IT Base Portacolonna PT Porta Guias FR Socle de Guidage



BG




Ref.	A	B	C	F	G	K	S	T	U	X	
BG.423016-..	42	30	30	7.5	15	28	M6	M6x35	16	15	20
BG.504020-..	50	40	36	9	22	34	M8	M8x40	20	15	20
BG.554024-..	55	40	40	9	22	38	M8	M8x45	24	15	20
BG.655028-..	65	50	45	12	26	45	M10	M10x50	28	15	20

IMPORTANT !
Indicate the desired **X** dimension after the reference.
Indicar al final de la referencia, la cota **X** deseada.
Gewünschte **X** Dimension angeben, nach der Referenznr.
Indicare la quota **X** desiderata alla fine del codice.
Indique o dimensão **X** desejada depois da referência.
Préciser le début de référence et le compléter par la dimension **X** souhaitée.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Patented



Max. 150°C


RC



SLIDE RETAINER

ES Retensor Corredera DE Schiebersicherung
IT Ritenore Carrello PT Retensor de Corrediças FR Blocage de Coulisseau

● Cad Insertion Point



K=Force to release the retainer.

ES K=Fuerza de desenganche del retensor.
DE K=Kraft zum entriegeln.
IT K=Forza di sgancio del ritenore.
PT K=Força necessária para libertar o retensor.
FR K=Force de libération de la retenue.

Ref.	A	B	C	E	F	G	H	K	R	T	SW
RC.123006	12	30	6x20	21	4.7	4	16	5 kg.	6	M5x16	3
RC.164008	16	40	8x20	28	5.7	5	15	7 kg.	8	M6x20	4
RC.205010	20	50	10x24	34	7.7	6	17	14 kg.	10	M8x25	5
RC.246012	24	60	12x32	42	9.7	7	23	21 kg.	12	M10x30	6
RC.328012	32	80	16x40	56	11.7	9	27	28 kg.	16	M12x35	8
RC.328016	32	80	16x40	56	15.7	9	25	38 kg.	16	M12x50	8

Patented
Max. 150°C




PO



OPTIONAL DOWEL PIN

ES Pasador Opcional DE Zylinderstift (Optional)
IT Riferimento Opzionale PT Cavilha Opcional FR Goupille Optionnel


● Cad Insertion Point




Ref.	L	M	N	P	SWa
P0.120320	12	M3x20	7.5	6	2
P0.150425	15	M4x25	10	8	2.5
P0.200530	20	M5x30	13	10	3
P0.250635	25	M6x35	16	12	4
P0.340850	34	M8x50	23	16	5

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Slide mechanical stop recommended



Patented
Max. 150°C


SLIDE RETAINER

ES Retensor Corredera DE Schiebersicherung
IT Ritenore Carrello PT Retensor de Corrediças FR Blocage de Coulisseau

● Cad Insertion Point



RCM





K=Force to release the retainer.

ES K=Fuerza de desenganche del retensor.
DE K=Kraft zum entriegeln.
IT K=Forza di sgancio del ritenore.
PT K=Força necessária para libertar o retensor.
FR K=Force de libération de la retenue.



Ref.	A	B	C	E	F	G	H	J	K	N	R	S	T	U
RCM.163808	16	38	8	25	7.6	7.6	4	10	10 kg.	7	8	M5	M6	9
RCM.204810	20	48	10	32	8.7	8.6	5	11	14 kg.	8	10	M6	M8	12
RCM.245712	24	57	12	37.5	9.6	9.6	6	12	18 kg.	9	12	M8	M10	15

Patented
Max. 150°C



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




AUTOMATIC RETAINER

ES Retensor Automático DE Zuhaltung Automatisch
IT Ritenore Automatico PT Retensor Automático FR Retenue Automatique


RA


● Cad Insertion Point



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation





2

UNDERCUTS

UNDERCUTS INDEX

ÍNDICE NEGATIVOS / INHALTSVERZEICHNIS HINTERSCHNEIDUNGEN
INDICE NEGATIVI / ÍNDICE NEGATIVOS / INDEX CONTRE DÉPOUILLES - CLIPS

50/

Double Rack Lifter
Doble Cremallera
Zweifach Zahnstangen-System
Doppia Cremagliera
Duplo Rack
Double Cremaillere



52/

DR Cooling Hose
Refrigeración DR
Kühlungsschlauch Für DR
Refrigerazione DR
Refrigeração DR
Refroidissement DR



53/

Adjustable Fixing
Fijación Regulable
Einstellbare Befestigung
Fissaggio Regolabile
Fixação Regulável
Fixation Reglable



54/

Xtreme Double Rack
Doble Cremallera Xtreme
Xtreme Zweifach Zahnstangen-System
Doppia cremagliera Xtreme
Xtreme Double Rack
Double Cremaillere Xtreme



56/

Cooled Rack Lifter
Doble Cremallera Refrigerada
Gekühltes Zweifach Zahnstangen System
Doppia Cremagliera con Refrigerazione
Duplo Rack Refrigerado
Double Rack Réfrigéré



57/

KR Cooling Hose
Tubo Refrigeración KR
KR Kühlungsschlauch
Sistema Refrigerazione KR
Tubo de Refrigeración KR
Tubo de Refroidissement KR



58/

Connection Hose
Tubo Conexión
Verbindungsschlauch
Tubo Collegamento
Tubo de Ligação
Tube de Liaison



58/

Cooling Distributor
Distribuidor Refrigeración
Verteilerschlauch
Distributore Refrigerazione
Distribuidor de Refrigeración
Distribution de Refroidissement



58/

90° Plate Connector
Conector Placa a 90°
90° Platten-Verbindungsstück
Collegamento Piastra a 90°
Conector de Placa a 90°
Connexion Dans la Plaque de 90°



60/

Smart Worm Lifter
Patin Smart Worm
Smart Worm Lifter
Smart Worm Lifter
Balancé Smart Worm
Patin Smart Worm



62/

Smart Worm Pin
Expulsor Smart Worm
Smart Worm Pin
Pin Smart Worm
Extractor Smart Worm
Ejection Smart Worm



63/

WP Adjustable Fixing
Fijación Regulable WP
WP Einstellbare Befestigung
Fissaggio Regolabile WP
Fixação Regulável WP
Fixation Reglable WP



64/

Flexible Core
Pinza Flexible
Flexibler Federauswerfer
Pinza Flessibile
Pinça Flexive
Éjecteur Flexible



65/

Standard Lifter
Patin Standard
Schrägschieber
Pattino Standard
Patim Standard
Patin Standard



66/

Sprung Core
Pinza Plana
Federnder Auswerfer
Pinza Plana
Pinça Plana
Éjecteur de Forme



67/

Sprung Core Extension
Alargo Pinza
Verlängerung Fed. Auswerfer
Prolunga Pinza
Acrescento da Pinça
Rallonge d'Éjecteur



68/

Xtra Sprung Core
Pinza Extra
Xtra Federnder Auswerfer
Pinza Plana Extra
Pinça Plana Extra
Éjecteur de Forme Extra



69/

PX Cutting Jig
Útil de Corte para PX
PX Anpassungslehre
Utensile per Lavorazione PX
Acessório para Corte da PX
PX Accessoire d'Ajustement



70/

Double Ejector
Expulsor Doble
Doppelauswerfer
Espulsore Doppio
Extractor Duplo
Éjecteur Double



71/

Tulip Ejector
Expulsor Elástico
Kreuzauswerfer
Espulsore Elastico
Extractor Elástico
Éjecteur Tulipe



72/

Dog Lifter - DL
Patin Vertical - DL
Vertikal Schrägschieber - DL
Pattino Automatico - DL
Patim Automatico - DL
Cale Automatique - DL



73/

Dog Lifter - DG
Patin Vertical - DG
Vertikal Schrägschieber - DG
Pattino Automatico - DG
Patim Automatico - DG
Cale Automatique - DG



74/

Horizontal and Adaptable Base
Base Deslizamiento
Führungsplatte für Waagerechte und Schräge Fläche
Base di Scorrimento
Base de Deslize
Embase de Mouvement



75/

Fixed Lifter Base
Deslizamiento Fijo
Gelenkstück für Schrägauswerfer
Scorrimento Fisso
Deslizamiento Fixo
Glissière Fixe



75/

Lifter Shaft
Varilla Figura
Stange für Geteilten Auswerfer
Asta per Inserto Figura
Haste Balancé
Queue d'aronde



76/

Undercut Base Unit
Soporte Deslizamiento
Schrägauswerfer Basisführung
Supporto di Scorrimento
Suporte Deslize
Douille de Guidage



76

Angled Guide Bush
Casquillo Inclinado
Schrägbuchse
Bussola Inclinata
Casquillo Inclinado
Cale Escamotable



77/

Special Sprung Core
Pinza Plana Especial
Sonder Federnder Auswerfer
Pinza Plana Speciale
Pinça Plana Especial
Éjecteur de Forme Special




DR

DOUBLE RACK LIFTER

ES Doble Cremallera DE Zweifach Zahnstangen-System
IT Doppia Cremagliera PT Duplo Rack FR Double Cremaillere

● Cad Insertion Point



Patented
Max. 150°C


DR16, DR22, DR28 & DR34
Mat. 1.2344
Hardened 44±2 HRC

DR40 & DR46
Mat. 1.7225
Hardened 48±2 HRC

DR16
1.5^{+0.05}
0.5^{-0.05}

Recommended R

IMPORTANT!
Length^{-0.1}



IMPORTANT!
Mirror Part.
Pieza Simétrica.
Symmetrisches Teil.
Versione a Specchio.
Peça em Espelho.
Pièce en Miroir.

Stroke 100	Stroke 125	X°	A	B	C	D	E	L100	P100	L125	P125	Q	R	T	U	V	Stroke 100-S	Stroke 125-S	SWa
DR.16100L-x	-	8 12 16	-	16 9 8	20 20	142 178	-	-	4	M5	M5	10	6	DR.16100L-x-S	-	3			
DR.22100L-x	DR.22125L-x	8 12 16	22	12 12	30 22	148 202	202	261	6.5	M6	M6	17	8	DR.22100L-x-S	DR.22125L-x-S	4			
DR.28100L-x	DR.28125L-x	8 12 16	20	28 16 14	36 28	152.5 214	194.5	266	8.5	M8	M8	23	8	DR.28100L-x-S	DR.28125L-x-S	5			
DR.34100L-x	DR.34125L-x	8 12 16	20	34 20 16	36 34	160.5 227	188.5	264	10.5	M8	M8	23	8	DR.34100L-x-S	DR.34125L-x-S	5			
DR.40100L-x	DR.40125L-x	8 12 16	20	40 22 20	36 40	170 244	204	284	10.5	M10	M10	20	10	DR.40100L-x-S	DR.40125L-x-S	6			
DR.46100L-x	DR.46125L-x	8 12 16	20	46 24 24	42 46	175 258	201	289	10.5	M10	M12	26	10	DR.46100L-x-S	DR.46125L-x-S	8			

HOW TO ORDER

Check page 48-49 for Min / Max β values

β° < 0 & β° = 0 β° > 0


DR 28 100L - 12 -10 — Standard — DR 28 100L - 12 +10

DR 28 100L - 12 -S -10 — Symmetrical — DR 28 100L - 12 -S +10

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation




Core Housing
Alojamiento Placa Punzón
Einbaumaße DR Führung
Sede nel Punzone
Alojamento Bucha
Logement dans l'empreinte



Stroke 100	Stroke 125	Stroke 200	F	FR1	FR2	G	H	J	K	M	N	S	T	W	Y	Z	SWb
DR.16100L-..	-	-	10	4.9	M8x1	4.6	4.6	3	2.35	3	2.8	2.5	M5	6	9	M4	4
DR.22100L-..	DR.22125L-.. / KR.22125L-..	-	13	5.3	M10x1	5.6	5.6	4.2	3.7	4.2	3.5	2.5	M6	8	12	M4	5
DR.28100L-..	DR.28125L-.. / KR.28125L-..	-	16	5.3	M10x1	7.5	7.5	5	5.4	4.8	4.8	2.5	M8	8	13.5	M4	5
DR.34100L-..	DR.34125L-.. / KR.34125L-..	-	16	5.3	M10x1	10.5	8	7	7	5	6	4	M8	8	16	M4	5
DR.40100L-..	DR.40125L-.. / KR.40125L-..	-	20	8.5	M12x1	11	11	7	8	7	7	4	M10	10	20	M6	6
DR.46100L-..	DR.46125L-.. / KR.46125L-..	-	25	8.5	M12x1	13	13	8	8	9	9	5	M12	10	24	M6	6
-	-	KR.58200L-..	28	8.5	M16x1.5	15.5	15.5	10	12.2	11.2	10	5	M14	12	30	M6	8
-	-	KR.76200L-..	36	14	M16x1.5	21	21	13	15.2	15.2	12	6	M18	12	36	M6	8

Installation

Instalación · Montage · Montaggio · Instalação · Montage



DR


Patented
Max. 150°C

DK

DR COOLING HOSE

ES Refrigeración DR DE Kühlungsschlauch für DR
IT Refrigerazione DR PT Refrigeração DR FR Refroidissement DR

Max. Cooling Fluid 50°C




Ref.	β°	H			
		DR.xxxxx-8	DR.xxxxx-12	DR.xxxxx-16	DR.xxxxx-20
DK.141818-...	Negative to 0°	10	10	10	10
	+1° to +9°	10	10	10	15
	+10° to +20°	10	15	20	25
	>+20°	15	20	25	30

IMPORTANT ! Indicate the required **L** dimension; the length will be rounded up to the next multiple of 25mm. Indicar la cota **L** deseada. Se suministrará redondeada al múltiplo superior de 25mm. Gewünschte Länge **L** angeben. Die Länge wird auf die nächste Vielfachen von 25 mm abgerundet. Indicare la lunghezza **L** desiderata; la quota richiesta sarà arrotondata al multiplo di 25mm superiore. Indicar a cota **L** desejada. Será fornecido com a dimensão múltipla de 25mm seguinte. Indiquer la cote **L** désirée. Celle-ci sera arrondie à un multiple supérieur de 25 mm.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




ADJUSTABLE FIXING

ES Fijación Regulable DE Einstellbare Befestigung
IT Fissaggio Regolabile PT Fixação Regulável FR Fixation Reglable

RF



Max. 150°C



Ref.	A	B	C	D	E	G	H	J	N	T	S	Compatible with
RF.161605	19.8	34	3	15.8	7.8	12.5	20	16	18	M5x45	8	DR16
RF.222006	23.8	34	4	19.8	11.8	14.5	24	20	18	M6x45	12	DR22/KR22
RF.282408	27.8	42	0	23.8	13.8	16.5	28	24	20	M8x50	14-16	DR28/DR34/KR28/KR34
RF.403210	35.8	42	0	31.8	19.8	20.5	36	32	24	M10x50	20-24	DR40/DR46/KR40/KR46

Installation Guidelines



Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



IMPORTANT !

XR

Patented
 Max. 150°C



IMPORTANT ! Mirror Part.
 Pieza Simétrica.
 Symmetrisches Teil.
 Versione specchiata.
 Peça em Espelho.
 Pièce en Miroir.

Stroke 100	X°	A	B	C	D	E	L	P	R	T	U	V	Stroke 100-S	SWa
XR34100L-x	24 28 32 36	34	20	16	36	34	159	225	M8	M8	23	8	XR34100L-x-S	5
XR40100L-x	24 28 32 36	40	22	20	36	40	170	240	M10	M10	20	10	XR40100L-x-S	6
XR46100L-x	24 28 32 36	46	24	24	42	46	174	255	M10	M12	26	10	XR46100L-x-S	8

! HOW TO ORDER

Check page 48-49 for Min / Max β values

β° < 0 & β° = 0 β° > 0

A	Stroke	X°	β
XR 34	100L	-28	-10

 Standard

A	Stroke	X°	β
XR 34	100L	-28	+10

A	Stroke	X°	β
XR 34	100L	-28	-10

 Symmetrical

A	Stroke	X°	β
XR 34	100L	-28	+10

XTREME DOUBLE RACK



ES Doble Cremallera Xtreme DE Extremier Double Rack
 IT Doppia cremagliera Xtreme PT Xtreme Double Rack FR Double Cremaillere Xtreme

● Cad Insertion Point

INSTALLATION GUIDELINES



ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation

Core Housing
 Alojamiento Placa Punzón
 Einbaumaße DR Führung
 Sede nel Punzone
 Alojamento Bucha
 Logement dans l'empreinte



Stroke 100	F	FR1	FR2	G	H	J	K	M	N	S	T	W	Y	Z	SWb
XR34100L-..	16	5.3	M10x1	8	10.5	6	5	7	6	4	M8	8	16	M4	5
XR40100L-..	20	8.5	M12x1	11	11	7	7	8	7	4	M10	10	20	M6	6
XR46100L-..	25	8.5	M12x1	13	13	9	9	8	8	5	M12	10	24	M6	8

Installation
 Instalación · Montage · Montaggio · Instalação · Montage



XR


Patented
 Max. 150°C

KR

COOLED RACK LIFTER

ES Doble Cremallera Refrigerada DE Gekühltes Zweifach Zahnstangen System
IT Doppia Cremagliera con Refrigerazione PT Duplo Rack Refrigerado FR Double Rack Réfrigéré

● Cad Insertion Point




Patented

Max. 80°C

KR COOLING HOSE

ES Tubo Refrigeración KR DE KR Kühlungsschlauch
IT Sistema Refrigerazione KR PT Tubo de Refrigeração KR FR Tube de Rrefroidissement KR

● Cad Insertion Point



FC

Max. 80°C

Ref.	A	C	D	E	F	G	H	J	K	L	M	N	O	P	R	U	Compatible With
FC.220500	40	15	18	483.5	16.5	18	31	27	16	1/8" GAS	M8x1	3.5	3	8	32	10	KR.22125L
FC.280500	50	18	25	475	25	18	41	27	16	1/8" GAS	M10x1	4.5	4	10	32	16	KR.28125L
FC.340500	50	18	25	475	25	18	41	27	16	1/8" GAS	M12x1	5	4.5	12	32	16	KR.34125L
FC.400500	54	20	25	475	25	20	44	30	18	1/4" GAS	M14x1	7	6.5	14	40	16	KR.40125L / KR.46125L

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Ref.	X°	A	B	C	E	F	G	H	L	P	Q	R	S	T	U	V	OR	Mirror Ref. -S	SW			
Stroke 125																						
KR.22125L-x	8	12	16	20	22	12	12	22	16	20	10.8	282	260	6.5	M6	-	M6	23	8	8x1.25	KR.22125L-x-S	4
KR.28125L-x	8	12	16	20	28	16	14	28	16	20	13.8	294.5	272	8.5	M8	-	M8	23	8	11x1.3	KR.28125L-x-S	5
KR.34125L-x	8	12	16	20	34	20	16	34	18	20	17.8	311.5	275	10.5	M8	-	M8	25	8	14x1.78	KR.34125L-x-S	5
KR.40125L-x	8	12	16	20	40	22	20	40	20	25	19.8	342	350	10.5	M10	-	M10	28	10	16x2	KR.40125L-x-S	6
KR.46125L-x	8	12	16	20	46	24	24	46	22	25	21.8	361	350	10.5	M12	-	M12	30	10	18x2	KR.46125L-x-S	8
Stroke 200																						
KR.58200L-x	8	12	16	-	58	30	30	66	25	55	26	362	430	13.5	M20	1/4"Gas	M14	60	12	21x2.5	KR.58200L-x-S	12
KR.76200L-x	8	12	16	-	76	40	40	80	30	60	34	392	470	17	M24	3/8"Gas	M18	70	12	28x3	KR.76200L-x-S	14

HOW TO ORDER


Check page 48-49 for Min / Max β values

β° < 0 & β° = 0 β° > 0

A Stroke X° β A Stroke X° β

KR 28 125L - 12 -10 — Standard — KR 28 125L - 12 +10

KR 28 125L - 12 -S -10 — Symmetrical — KR 28 125L - 12 -S +10



IMPORTANT



Ref.	Q					
	β≤0°	0°<β≤10°	10°<β≤20°	20°<β≤25°	25°<β≤30°	30°<β≤35°
KR.xx125L-8	10	15	18	20	23	25
KR.xx125L-12	10	16	22	25	29	-
KR.xx125L-16	10	18	26	31	-	-
KR.xx125L-20	10	20	31	-	-	-

MK

CONNECTION HOSE

ES Tubo Conexión DE Verbindungsschlauch
IT Tubo Collegamento PT Tubo de Ligação FR Tube de Liaison

● Cad Insertion Point





Ref.
MK.120300

Max.
80°C

RD

COOLING DISTRIBUTOR

ES Distribuidor Refrigeración DE Verteilerschlauch
IT Distributore Refrigerazione PT Distribuidor de Refrigeração FR Distribution de Refroidissement




Ref.
RD.182012

Max.
80°C

CK

90° PLATE CONNECTOR

ES Conector Placa a 90° DE 90° Platten-Verbindungsstück
IT Collegamento Piastra a 90° PT Conector de Placa a 90° FR Connexion Dans la Plaque de 90°





Ref.
CK.181839

Max.
80°C

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation






WL

Patented
 Max. 120°C

SMART WORM LIFTER

ES Patín Smart Worm DE Smart Worm Lifter
 IT Smart Worm Lifter PT Balancé Smart Worm FR Patin Smart Worm

● Cad Insertion Point






Ref.	A	B	C	D	d ₁	d ₂	d ₃	E	F	G	J	K	L	M	N	P	S	SW	T	t ₁	W	d ₄	d ₅	R	t ₂	U	V	Z	CR(N)	Stroke	SWa	SWb
WL_080100	8	9	M5	5.5	16	19.8	15.8	3.5	18	M5	6	9.5	205	4.5	10	M6	22	7	13	M5x45	26	20	16	6	M6	4.5	5.5	40	1.500	100	5	4
WL_080125	8	9	M5	5.5	16	19.8	15.8	3.5	18	M5	6	9.5	240	4.5	10	M6	22	7	13	M5x45	26	20	16	6	M6	4.5	5.5	50	1.500	125	5	4
WL_120100	12	13	M8	9.4	19.5	23.8	19.8	6	24	M6	8	13	205	6.2	14	M8	28	11	18	M6x45	28	24	20	8	M8	4	8	40	2.500	100	6	5
WL_120125	12	13	M8	9.4	19.5	23.8	19.8	6	24	M6	8	13	240	6.2	14	M8	28	11	18	M6x45	28	24	20	8	M8	4	8	50	2.500	125	6	5


INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation

IMPORTANT
 Design a Mechanical Stopper on the insert.
 Realice un Tope Mecánico en el inserto.
 Der Benutzer konstruiert selbst den mechanischen Anschlag am Einsatz.
 Realizzare un Fermo Meccanico sull'inserto.
 Criar um Batente Mecânico no postigo moldante.
 Créer un Arrêt Mécanique sur la pièce de la partie moulante.



X°	WL_...x100		WL_...x125	
	H	Y	H	Y
1°	1.74	0.60	2.18	0.60
2°	3.49	1.20	4.36	1.20
3°	5.24	1.80	6.55	1.80
4°	6.99	2.40	8.74	2.40
5°	8.75	3.00	10.90	3.00
Max. 6°	10.50	3.50	13.10	3.50



WL


Patented
 Max. 120°C

WP

SMART WORM PIN

ES Expulsor Smart Worm DE Smart Worm Pin
IT Pin Smart Worm PT Extractor Smart Worm FR Ejection Smart Worm

● Cad Insertion Point





Ref.	A	B	C	D	F	G	L	Z	CR (N)	Max. Stroke	Max. Torque
WP.060030	6	90	M4	4.5	12	10	108	30	1.000	30	8N/m
WP.060060	6	120	M4	4.5	12	10	138	35	1.000	60	8N/m
WP.080030	8	90	M5	5.5	18	12	110	30	1.500	30	12N/m
WP.080060	8	120	M5	5.5	18	12	140	35	1.500	60	12N/m

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

IMPORTANT
Design a Mechanical Stopper on the insert.
Realice un Tope Mecánico en el inserto.
Der Benutzer konstruiert selbst den mechanischen Anschlag am Einsatz.
Realizzare un fermo meccanico sull'inserto.
Criar um batente mecânico no postigo moldante.
Créer un arrêt mécanique sur la pièce de la partie moulante.




X°	Y	WP.xx0030	WP.xx0060
1°	0.60	0.52	1.04
2°	1.20	1.05	2.09
3°	1.80	1.57	3.14
4°	2.40	2.10	4.19
5°	3.00	2.63	5.25
Max. 6°	3.50	3.15	6.31

WP ADJUSTABLE FIXING

ES Fijación Regulable WP DE WP Einstellbare Befestigung
IT Fissaggio Regolabile WP PT Fixação Regulavel WP FR Fixation Reglable WP


● Cad Insertion Point



Ref.	A	B	SW	Compatible With
WF.061608	6	3.1	5	WP.060xxx
WF.081608	8	4.1	7	WP.080xxx

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




WF

Max. 120°C

PF

FLEXIBLE CORE


ES Pinza Flexible DE Flexibler Federauswerfer
IT Pinza Flessibile PT Pinça Flexível FR Ejecteur Flexible



Ref.	A	B	C	F	G	H	L	M	N	P	S	Balinit C®	Hardened
PF.044150	4	8	24	2.5	6	6	150	12	14	0.8	30	•	52±2 HRC
PF.0441WB	4	8	24	2.5	6	6	150	12	14	0.8	30	-	56±2 HRC
PF.054150	5	8	24	2.5	6	6.5	150	12	14	0.8	30	•	52±2 HRC
PF.0541WB	5	8	24	2.5	6	6.5	150	12	14	0.8	30	-	56±2 HRC
PF.064200	6	12	30	2.8	8	7.5	200	18	20	1	36	•	52±2 HRC
PF.0642WB	6	12	30	2.8	8	7.5	200	18	20	1	36	-	56±2 HRC
PF.084200	8	14	30	2.8	8	9	200	18	20	1	36	•	52±2 HRC
PF.0842WB	8	14	30	2.8	8	9	200	18	20	1	36	-	56±2 HRC
PF.104200	10	16	30	2.8	8	11	200	18	20	1	36	•	52±2 HRC
PF.1042WB	10	16	30	2.8	8	11	200	18	20	1	36	-	56±2 HRC
PF.124200	12	18	30	2.8	8	13	200	18	20	1	36	•	52±2 HRC
PF.1242WB	12	18	30	2.8	8	13	200	18	20	1	36	-	56±2 HRC


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



STANDARD LIFTER


ES Patin Standard DE Schrägschieber
IT Pattino Standard PT Patim Standard FR Patin Standard



Ref.	A	B	C	D	G	M	N	V
PS.062250	6.2	10	12	6	3.4	12	16	8
PS.082250	8.2	12	14	6	4	12	16	15
PS.102250	10.2	14	16	8	4.2	14	18	15
PS.122250	12.2	16	18	8	4.2	14	18	20

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



PS

Patented


Max. 150°C

PW

Patented
Max. 150°C

SPRUNG CORE


ES Pinza Plana DE Flexibler Federauswerfer
IT Pinza Piana PT Pinça Plana FR Ejecteur de Forme



Ref.	A	B	C	D	E	G	K	L	M	N	R	T	U	V	W	Bushing
PW.060622	6	6.2	22	9	3.5	-	3.5	125	16	18	1.25	M4x36	12	5	M4x16 (DIN7991)	-
PW.060630	6	6.2	30	10	3.5	12	4.5	175	20	26	1.25	M4x36	12	5	M4x16 (DIN7991)	•
PW.060822	6	8.2	22	9	3.5	-	3.5	125	16	18	1.25	M4x36	12	5	M4x16 (DIN7991)	-
PW.060830	6	8.2	30	10	3.5	12	4.5	175	20	26	1.25	M4x36	12	5	M4x16 (DIN7991)	•
PW.080825	8	8.2	25	11.5	4.5	-	4.5	140	18	21	2	M5x36	14	6	M5x16 (DIN7984)	-
PW.081025	8	10.2	25	11.5	4.5	-	4.5	140	18	21	2	M5x36	14	6	M5x16 (DIN7984)	-
PW.081030	8	10.2	30	11.2	4.5	12	4.5	175	20	26	2	M5x36	14	6	M5x16 (DIN7984)	•
PW.081225	8	12.2	25	11.5	4.5	-	4.5	140	18	21	2	M5x36	14	6	M5x16 (DIN7984)	-
PW.081230	8	12.2	30	11.2	4.5	12	4.5	175	20	26	2	M5x36	14	6	M5x16 (DIN7984)	•
PW.101430	10	14.2	30	13.6	5.5	16	5.5	175	20	26	2.5	M6x36	18	8	M6x16 (DIN7984)	•
PW.101630	10	16.2	30	13.6	5.5	16	5.5	175	20	26	2.5	M6x36	18	8	M6x16 (DIN7984)	•
PW.101830	10	18.2	30	13.6	5.5	16	5.5	175	20	26	2.5	M6x36	18	8	M6x16 (DIN7984)	•

Installation Guidelines



Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



SPRUNG CORE EXTENSION

ES Alargo Pinza DE Verlängerung Fed. Auswerfer
IT Prolunga Pinza PT Acrescento da Pinça FR Rallonge d'Ejecteur

● Cad Insertion Point




Ref.	A	C	R	S	T	U	V	SW
AP.080615	8	6	1.25	9.5x2	M4 (DIN7991)	14	5	2.5
AP.100815	10	8	2	11.5x2	M5 (DIN7984)	16	6	3
AP.121015	12	10	2.5	14.5x2.5	M6 (DIN7984)	20	8	4

IMPORTANT !
Enables a standard length of the PW up to 315mm.
Permite un alargamiento extra de la PW hasta 315mm.
Verlängerung PW bis 315 mm möglich.
Permette un prolungamento extra della PW fino a 315mm.
Possibilidade de obter um comprimento standard de 315mm.
Possibilitè d'obtenir une longueur standard de 315mm.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



AP


Patented
Max. 150°C

PX

XTRA SPRUNG CORE

ES Pinza Extra DE Xtra Federnder Auswerfer
IT Pinza Piana Extra PT Pinça Plana Extra FR Ejecteur de Forme Extra

● Cad Insertion Point







Ref.	A	B	D	E	F	L=175		L=250		L=325		N	Q
						≈G	Bushing	≈G	Bushing	≈G	Bushing		
PX.060630-...	6	6.2	10	3.5	12.5	60	-	80	●	80	●	2.5	12
PX.060830-...	6	8.2	10	3.5	12.5	60	-	80	●	80	●	2.5	12
PX.081030-...	8	10.2	11.2	4.5	13.5	60	-	80	●	80	●	3.5	14
PX.081230-...	8	12.2	11.2	4.5	13.5	60	-	80	●	80	●	3.5	14

IMPORTANT ! Indicate the desired **L** dimension after the reference.
Indicar al final de la referencia, la cota **L** deseada.
Gewünschte Länge (**L**) angeben.
Indicare la quota **L** desiderata alla fine del codice.
Indique o dimensão **L** desejada depois da referência.
Indiquer la cote **L** désirée per compléter le référence.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




PX CUTTING JIG

ES Útil de Corte para PX DE PX Anpassungslehre
IT Utensile per Lavorazione PX PT Acessório para Corte da PX FR PX Accessoire d'Ajustement




CX



Use Guidelines

Consejos de Uso · Richtlinien zur Verwendung · Consigli di Uso · Instruções de Utilização · Mode d'Emploi



1 Insert the PX into the corresponding slot, for 6 or 8mm. shank. Ensure that the shape of the PX head is adjusted in the housing support.

ES Insertar la PX en el alojamiento correspondiente, según sea de diámetro 6 u 8. Verificar que haga tope el perfil de la pinza con el alojamiento del útil.

DE Den federnden Auswerfer PX in den CX einsetzen. Prüfen, dass der federnde Auswerfer am Profil der Anpassungslehre richtig sitzt.

IT Inserire la PX nella relativa sede, a seconda del diametro 6 o 8. Verificare che la testa della pinza sia in battuta sulla sporgenza all'interno dell'utensile.

PT Colocar a PX no alojamento correspondente, em função do diâmetro da haste de 6 ou 8 mm. Verificar se o batente da PX está completamente encostado ao encosto do acessório.

FR Positionner le PX dans son logement correspondant au diamètre de la tige, 6 ou 8 mm. Vérifier que la vis centrale soit en pression contre les faces de mise en position.

2 Use an allen key to select the correct option: flat ● or ● round.

ES Utilizar una llave allen para seleccionar la posición de cara plana ● o ● redonda, según sea el caso.

DE Mit einem Imbusschlüssel wählen Sie das runde ● oder flache ● Profil.

IT Usare una brugola per ruotare l'inserto in basso, a seconda che il gambo sia piano ● o rotondo ●.

PT Utilizar uma chave de allen para seleccionar a posição adequada, face plana ● ou redonda ●.

FR Utiliser une clé 6 pans afin de positionner le type de cale, forme ronde ● ou plane ●.

3 Cut the PX to the required dimension.

ES Cortar la PX a la dimensión requerida.

DE Den PX auf das gewünschte Maß kürzen.

IT Tagliare la PX alla quota necessaria.

PT Cortar a PX na dimensão requerida.


FR Couper le PX suivant la longueur voulue.

ED

DOUBLE EJECTOR

ES Expulsor Doble DE Doppelauswerfer
IT Espulsore Doppio PT Extractor Duplo FR Éjecteur Double

● Cad Insertion Point




Ref.	A	B	C	D	E	G	H	Balinit C®
ED.068200	6	12	14	10	14	6	10	●
ED.088200	8	14	16	12	16	8	12	●
ED.108200	10	16	18	14	18	8	14	●
ED.128200	12	16	18	16	20	8	15	●

IMPORTANT ! Special lengths of 275 and 350mm. upon request.
Largos especiales de 275 y 350mm. bajo demanda.
Sonderlängen von 275 und 350mm. auf Anfrage.
Lunghezza speciale 275/350mm. su richiesta.
Dimensões especiais de 275 e 350mm. quando pedido.
Longueurs spéciales de 275 et 350mm. sur demande.

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



TULIP EJECTOR

ES Expulsor Elástico DE Kreuzauswerfer
IT Espulsore Elastico PT Extractor Elástico FR Éjecteur Tulipe

● Cad Insertion Point




IMPORTANT ! Special lengths of 250 and 325mm. upon request.
Largos especiales de 250 y 325mm. bajo demanda.
Sonderlängen von 250 und 325mm. auf Anfrage.
Lunghezza speciale 250/325mm. su richiesta.
Dimensões especiais de 250 e 325mm. quando pedido.
Longueurs spéciales de 250 et 325mm. sur demande.

Ref.	A	B	C	D	E	H	K	U	Balinit C®
EE.060175	6	10	12	12	-	9	2.8	0.5	●
EE.082175	8	12	14	14	2	11	2.8	0.5	●
EE.103175	10	14	16	16	3	13	2.8	0.5	●
EE.124175	12	16	18	18	4	15	3	0.5	●
EE.168175	16	20	22	22	8	19	3	1	●

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



DL

DOG LIFTER - DL

ES Patin Vertical - DL DE Vertikal Schrägschieber - DL
IT Pattino Automatico - DL PT - DL FR Cale Automatique - DL





Ref.	A	D	T	X
DL.143465	34	12	M4x20	18
DL.144065	40	18	M4x25	26
DL.144665	46	22	M4x30	31

IMPORTANT !
Special angles available upon request, please contact: technical@cumsa.com
Ángulos especiales disponibles bajo demanda, por favor, contactar: technical@cumsa.com
Sonderwinkeln auf Anfrage, bitte kontaktieren Sie: technical@cumsa.com
Angoli speciali disponibili su richiesta, nel caso, scrivete a: technical@cumsa.com
Ángulos especiais por encomenda, por favor contactar: technical@cumsa.com
Pour les angles spécifiques, merci de contacter: technical@cumsa.com

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




IMPORTANT !
Length ±0.05

LR
100

DOG LIFTER - DG

ES Patin Vertical - DG DE Vertikal Schrägschieber - DG
IT Pattino Automatico - DG PT Patin Automatico - DG FR Cale Automatique - DG





Ref.	A	D	T	X
DG.264592	45	16	M6x30	16
DG.265092	50	22	M6x30	22
DG.265592	55	26	M6x35	26

IMPORTANT !
Special angles available upon request, please contact: technical@cumsa.com
Ángulos especiales disponibles bajo demanda, por favor, contactar: technical@cumsa.com
Sonderwinkeln auf Anfrage, bitte kontaktieren Sie: technical@cumsa.com
Angoli speciali disponibili su richiesta, nel caso, scrivete a: technical@cumsa.com
Ángulos especiais por encomenda, por favor contactar: technical@cumsa.com
Pour les angles spécifiques, merci de contacter: technical@cumsa.com


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



IMPORTANT !
Length ±0.05

LD
101



Patented
Max. 150°C

Patented
Max. 150°C





BD

HORIZONTAL AND ADAPTABLE BASE
 ES Base Deslizamiento DE Führungsplatte für Waagerechte und Schräge Fläche
 IT Base di Soccorimento PT Base de Deslize FR Embase de Mouvement



● Cad Insertion Point

Horizontal Undercuts




Ref.	A	C	D	E	F	G	L	P	Q	R	T	Z
BD.122036	12	36	28	4	4.8	11.5	10	5	5	4	M5	20
BD.142266	14	66	42	4	6.3	11.5	10	5	5	4	M5	22
BD.162440	16	40	30	5	6.3	13.5	12	6	5	5	M6	24
BD.203260	20	60	44	5	8.3	19	15	6	5	5	M6	32
BD.253872	25	72	56	7	10.3	21	18	8	5	6	M8	38
BD.314890	31	90	74	8	13.3	28	18	10	9	8	M10	48

Angled Undercuts



Ref.	A	C	D	E	F	G	L	P	Q	R	T	Z
BD.122836	12	36	28	4	4.8	11.5	10	5	5	4	M5	28
BD.143866	14	66	42	4	6.3	11.5	10	5	5	4	M5	38
BD.163240	16	40	30	5	6.3	13.5	12	6	5	5	M6	32
BD.204060	20	60	44	5	8.3	19	15	6	5	5	M6	40
BD.254672	25	72	56	7	10.3	21	18	8	5	6	M8	46
BD.315890	31	90	74	8	13.3	28	18	10	9	8	M10	58



FIXED LIFTER BASE


ES Deslizamiento Fijo DE Gelenkstück für Schrägauswerfer
 IT Scorrimento Fisso PT Deslizamento Fixo FR Glissière Fixe

● Cad Insertion Point



DF

Ref.	A	B	C	D	E	F	H	T	SW
DF.061220	6	12	20	11.5	12	0.5	10	M4x12	3
DF.081220	8	12	20	11.5	12	0.5	10	M5x12	4
DF.101624	10	16	24	13.5	14	0.5	12	M6x16	5
DF.121624	12	16	24	13.5	14	1	12	M8x16	6
DF.162032	16	20	32	19	18	1.5	16	M8x25	6
DF.202538	20	25	38	21	21	1.5	19	M10x25	8
DF.253148	25	31	48	28	26	2	24	M12x35	10




Max. 150°C

LIFTER SHAFT

ES Varilla Figura DE Stange für Geteilten Auswerfer
 IT Asta per inserto figura PT Haste Balancé FR Queue d'Aronde

● Cad Insertion Point



Ref.	A	E	L	M	U	V	X
VI.064200	6	10	15	214	0.5	12	5
VI.085200	8	12	20	217	0.5	12	10
VI.106200	10	14	20	219	0.5	14	15
VI.127200	12	16	20	222	1	14	20



VI

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Patented Max. 150°C

SD

UNDERCUT BASE UNIT

ES Soporte Deslizamiento DE Schrägäuswerfer Basisführung
IT Supporto di Scorrimento PT Suporte Deslize FR Douille de Guidage

● Cad Insertion Point



Ref.	A	B	C	D	E	L	M	P
SD.3220GR	32	37	20	27	18	80	180	10
SD.3824GR	38	40	24	28	19	80	210	12
SD.4528GR	45	44	28	30	21	100	250	16


IMPORTANT !
Longer **M** available as special.
Posibilidad de varilla (cota **M**) más larga.
Längere **M**-Maße als Sonderfertigung verfügbar.
Possibilità di avere **M** speciale di lunghezza maggiore.
Cota **M** de maiores dimensões por encomenda.
Possibilité de tige plus longue (cote **M**).

IMPORTANT !
The unit and the rod are delivered separately.
El cuerpo y la varilla se entregan separados.
Die Schubstange ist nicht montiert.
Il gruppo e l'asta si consegnano separatamente.
O corpo e a haste são fornecidos em separado.
Le corps et la tige sont livrés démontés.

SPECIAL SPRUNG CORE

ES Pinza Plana Especial DE Sonder Federnder Auswerfer
IT Pinza Piana Speciale PT Pinça Plana Especial FR Ejecteur de Forme Special

SPECIAL



IMPORTANT !
The dimensions A, R and X° will be determined by CUMSA depending on the head dimensions required by the customer.
Las cotas A, R y X° serán determinadas en CUMSA según las dimensiones de la cabeza solicitadas por el cliente.
Die Maße A, R, und X° werden von CUMSA festgelegt und sind abhängig von den gewünschten Kopfmaßen.
Le quote A, R e X° saranno determinate da CUMSA secondo le dimensioni della testa richieste dal cliente.
A cota A, R y X° serão determinadas pela CUMSA segundo as dimensões da cabeça solicitada pelo cliente.
Les cotes A, R et X° sont déterminées par CUMSA en fonction des dimensions de la tête de l'éjecteur.

Ref.	B	C	D	E	F	L	Quantity

How To Order This Part?

¿Cómo Realizar un Pedido? · Bestellvorgang · Come Realizzare un Ordine? · Como Realizar um Pedido? · Comment Effectuer une Ommande?

1 ORDER. When the enquiry is received, Cumsa will design the sprung core and send the drawing to the customer, with the unit price and the delivery time, for acceptance.

ES PEDIDO. Una vez recibida la solicitud, CUMSA diseñará el plano de la pieza y lo enviará al cliente, junto con el precio y el plazo para su aprobación.

DE BESTELLUNG. Nach Erhalt der Anfrage erstellt CUMSA eine Zeichnung des Fed. Auswerfers incl. Stückpreis und Lieferzeit, die vom Kunden freigegeben werden muss.

IT ORDINE. Una volta ricevuta la richiesta, CUMSA disegnerà il progetto corrispondente e lo invierà al cliente, unito al prezzo e al tempo di consegna, per la sua approvazione.

PT PEDIDO. Uma vez recebida a consulta, a CUMSA desenha a peça e envia o mesmo para o cliente, com o preço e prazo para a sua aprovação.

FR COMMANDE : A la réception de votre demande, CUMSA dessinera le plan de détail de votre éjecteur spécial. Le dessin, ainsi que le prix et le délai seront joints dans l'attente de votre validation.

2 DELIVERY. 4 weeks, from order confirmation.

ES ENTREGA. El plazo de entrega es de 4 semanas, tras la confirmación del pedido.

DE LIEFERUNG. Lieferzeit 4 Wochen ab Auftragsbestätigung.

IT REALIZZAZIONE. Il tempo di consegna è di 4 settimane, data conferma ordine.

PT ENTREGA. O prazo de entrega é de 4 semanas a partir da data de confirmação.

FR REALISATION : Le délai de livraison est de 4 semaines, à partir de la validation de l'offre.

Patented

Max. 150°C

CI

ANGLED GUIDE BUSH

ES Casquillo Inclinado DE Schrägbuchse
IT Bussola Inclinata PT Casquilho Inclinado FR Cale Escamotable




● Cad Insertion Point



Ref.	A	B	C	D	E	G	H	S	T	U	X	SW
CI.3034GR-5	30	34	34	16	20	6	0	M4x6	M6x16	10	5	4
CI.3438GR-5	34	38	38	20	24	8	0	M6x6	M8x20	12	5	5
CI.4040GR-5	40	40	44	20	27	8	0	M6x6	M8x20	16	5	5
CI.3034GR-10	30	34	34	16	20	6	7	M6x6	M6x16	10	10	-
CI.3438GR-10	34	38	38	20	24	8	8.5	M8x6	M8x20	12	10	-
CI.4040GR-10	40	40	44	20	27	8	8.5	M8x6	M8x20	16	10	-
CI.3034GR-15	30	34	34	16	20	6	7	M6x6	M6x16	10	15	-
CI.3438GR-15	34	38	38	20	24	8	8.5	M8x6	M8x20	12	15	-
CI.4040GR-15	40	40	44	20	27	8	8.5	M8x6	M8x20	16	15	-
CI.3034GR-20	30	34	34	16	20	6	7	M6x6	M6x16	10	20	-
CI.3438GR-20	34	38	38	20	24	8	8.5	M8x6	M8x20	12	20	-
CI.4040GR-20	40	40	44	20	27	8	8.5	M8x6	M8x20	16	20	-

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione
Instruções de Instalação · Mode d'Installation





3

EJECTION

EJECTION INDEX

ÍNDICE EXPULSIÓN / INHALTSVERZEICHNIS AUSWERFEN
INDICE ESPULSIONE / ÍNDICE EXTRACÇÃO / INDEX ÉJECTIONS


<p>82/</p>  <p>Plate Retainer Retensor Placas Platten Verriegelung Ritensore Piastra Retensor de Placa Tire Plaques</p>	<p>82/</p>  <p>Stroke Limiter Limitador de Recorrido Hubbegrenzer Limitatore Apertura Limitador de Curso Limiteur de Course</p>	<p>83/</p>  <p>Modular Retainer Retensor Modular Mitnehmer Modular Ritensore Modulare Retensor Modular Retenue Modulée</p>	<p>96/</p>  <p>External Synchronized Plates Sincronizador de Placas Externo Externe Plattensynchronisation Sincronizzatore di Piastre Esterno Sincronizador Chapas Externo Synchronisation Mouvement Plaques</p>	<p>98/</p>  <p>EX-EY-EZ Rod Extension Alargo EX-EY-EZ EX-EY-EZ Verlängerungsstange Estensione EX-EY-EZ Extensor para EX-EY-EZ Extension pour EX-EY-EZ</p>	
<p>84/</p>  <p>Latch Lock Gatillo Simple Klinkenzug Gancia Sgancia Gatilho Simples Crochet Ouverture Gradué</p>	<p>85/</p>  <p>Internal Latch Lock Gatillo Interno Interner Klinkenzug Gancia Sgancia Interno Gatilho Interno Tire Plaque Interne</p>	<p>86/</p>  <p>Superior Double Ejector Doble Expulsión Superior Zweistufenauswerfer DX Doppia Espulsione Superiore Dupla Extracção Superior Double Ejection Supérieure</p>	<p>98/</p>  <p>EX-EY-EZ External Fixing Fijación Externa EX-EY-EZ EX-EY-EZ Externe Befestigung EX-EY-EZ Fissaggio Esterno Fixação Externa EX-EY-EZ Fixation Externe pour EX-EY-EZ</p>	<p>99/</p>  <p>Accelerated Ejector Acelerador Expulsión Vorschub-Auswerfer Acceleratore di Espulsione Acelerador de Extracção Accélérateur d'Éjection</p>	<p>100/</p>  <p>Threaded Limiter Limitador con Rosca Auswerfer Begrenzer mit Gewindeaufnahme Limitatore Filettato Limitador com Rosca Limiteur avec Vis</p>
<p>87/</p>  <p>Superior Plate Separator Separador Placas Superior Superior Zweistufenauswerfer Separatore Piastra Superiore Separador de Chapas Superior Séparateur de Plaques</p>	<p>88/</p>  <p>External Superior Plate Separator Separador Placas Superiores Externa Externe Obere Plattentrennung Separatore Piastra Superiori Esterno Separador Chapas Superior Externo Séparateur Plaque Supérieure Externe</p>	<p>100/</p>  <p>Threaded Limiter Adapter Adaptador para Limitador Roscado Gewindeadapter Adattatore per Limitatore Filettato Adaptador para Limitador Roscado Adaptateur pour Limiteur avec Vis</p>	<p>101/</p>  <p>Dog Lifter Limiter Limitador Patín Hubbegrenzer Limitatore Pattino Limitador Patim Automático Limiteur</p>	<p>102/</p>  <p>Ejector Base Base Expulsora Aufnahme für Auswerfer Base Espulsore Base de Extractores Embases d'Éjection</p>	
<p>90/</p>  <p>Plate Accelerator Elevador Placas Auswerferplatten-Beschleuniger Acceleratore Piastra Espulsione Acelerador de Chapa Accélérateur Batterie d'Éjection</p>	<p>91/</p>  <p>Double Ejection Doble Expulsión Zweistufenauswerfer Doppia Espulsione Dupla Extracção Double Ejection</p>	<p>92/</p>  <p>Rear Double Ejector Doble Expulsión Inferior Zweistufenauswerfer DY Doppia Espulsione Inferiore Dupla Extracção Inferior Double Ejection inférieure</p>	<p>103/</p>  <p>Headless Ejector Pin Varilla Expulsora Auswerfer ohne Kopf Asta Espulsore Extractor Sem Cabeça Ejecteur sans Tête</p>	<p>103/</p>  <p>Headless Ejector Sleeve Tubular Expulsión Auswerferhülsen ohne Kopf Espulsore Tubolare Extractor Tubular sem Cabeça Tubulaire sans Tête</p>	<p>104/</p>  <p>Ejector Foot Distanciador Placa Anschlagscheibe Distanziale Piastra Botão de Encosto Repos de Batterie</p>
<p>93/</p>  <p>Compact Double Ejection Doble Expulsión Compacta Kompakter Zweistufenauswerfer Doppia Espulsione Compatta Dupla Extracção Compacta Double Ejection Compact</p>	<p>94/</p>  <p>External Double Ejection Doble Expulsión Externa Externer Zweistufenauswerfer Doppia Espulsione Esterna Dupla Extracção Externa Double Ejection Externe</p>	<p>104/</p>  <p>Safety Stopper Tope Magnético Abstandhalter, magnetisch Blocco Magnetico Bloco Magnético Butée Magnétique</p>	<p>105/</p>  <p>Ejector Plate Spacer Distanciador Placa Auswerferplatte Abstandhalter Distanziale Piastra Espaçador de Chapas Entretoise de Passage</p>	<p>105/</p>  <p>Shock Absorber Tope Amortiguador Dämpfungsscheibe Blocco Ammortizzante Batente Amortecedor Repos de Batterie avec Amortissement</p>	

PR



PLATE RETAINER

ES Retensor Placas DE Platten Verriegelung
IT Ritenore Piastra PT Retensor de Placa FR Tire Plaques




MODULAR RETAINER

ES Retensor Modular DE Mitnehmer Modular
IT Ritenore Modulare PT Retensor Modular FR Retenue Modulée




RM



IMPORTANT !
 K=Approximate resistance value that can be obtained by grouping clips.
 K=Valor aproximado de resistencia que se puede obtener agrupando clips.
 K=Zirka Widerstand beim Einbau entsprechend obiger Darstellung.
 K=Valore approssimativo di resistenza che si può ottenere raggruppando più ritenori.
 K=Valor aproximado de resistência que se pode obter agrupando clips.
 K=Valeur approximative que l'on peut obtenir en assemblant les retenues.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




SL




STROKE LIMITER

ES Limitador de Recorrido DE Hubbegrenzer
IT Limitatore Apertura PT Limitador de Curso FR Limiteur de Course



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




GS

LATCH LOCK

ES Gatillo Simple DE Klinkezug
IT Gancia Sgancia PT Gatilho Simples FR Crochet Ouverture Gradué

● Cad Insertion Point




IMPORTANT !
After selecting the required stroke, fix the scale lever.
Después de seleccionar el recorrido deseado, fijar la leva graduada.
Nach der Wahl des gew. Hubes befestigen Sie die skalierte Leiste.
Dopo aver selezionato la corsa richiesta, fissare la riga graduata.
Depois de seleccionar o curso adequado, fixe a régua graduada.
Après avoir sélectionné la course d'ouverture, fixer la règle graduée.

Ref.	A	B	C	D	E	F	G	H	L	M	N	P (x2)	R (x4)	S (x2)	T	V	Scale	SW
GS.226616	22	66	16	38	75	30	25	32	105	10	15	Ø6x20	Ø6x30	M6x30	M6x35	10	40	4
GS.368619	36	86	19	46	102	43	32	42.7	153	12	20	Ø8x24	Ø8x36	M8x35	M8x40	11.5	60	5
GS.421024	42	106	24	56	124	51	40	50.2	190	15	24.5	Ø10x30	Ø10x40	M10x40	M10x45	14	80	6

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



INTERNAL LATCH LOCK

ES Gatillo Interno DE Interner Klinkezug
IT Gancia Sgancia Interno PT Gatilho Interno FR Tire Plaque Interne

● Cad Insertion Point




Ref.
MX.143662

IMPORTANT !
2 BF.241215 units included. More units can be ordered separately.
Se suministran 2 unidades de BF.241215. Se pueden pedir más unidades por separado.
2 St. BF.241215 enthalten. Mehr Einheiten können einzeln bestellt werden.
Vengono forniti 2 BF.241215. E' possibile ordinarne altri separatamente.
2 unidades BF.241215 incluídas. Possibilidade de encomendar mais unidades individualmente.
2 unités BF.241215 inclus. Possibilité de commander à la pièce.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Patented
Max. 150°C


Patented
Max. 150°C

DX

SUPERIOR DOUBLE EJECTOR

ES Doble Expulsión Superior DE Zweistufenauswerfer DX
IT Doppia Espulsione Superiore PT Dupla Extracção Superior FR Double Ejection Supérieur



● Cad Insertion Point



Ref.	A	B	C	D	E	F	G	H	J	K	L	M	N	L1	L2
DX.142622	14	26	16	30	34	20	16	4	125	7.2	243	M6	21	42	48
DX.163027	16	30	21	34	44	23	18	6	152	8	314	M8	24	54	80

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Patented


Max. 150°C



SUPERIOR PLATE SEPARATOR

ES Separador Placas Superior DE Superior Zweistufenauswerfer
IT Separatore Piastra Superiore PT Separador de Chapas Superior FR Séparateur de Plaques

● Cad Insertion Point





Ref. SX.256062

IMPORTANT !
2 BF.423222 units included. More units can be ordered separately.
Se suministran 2 unidades de BF.423222. Se pueden pedir más unidades por separado.
2 St. BF.423222 enthalten. Mehr Einheiten können einzeln bestellt werden.
Vengono forniti 2 BF.423222. E' possibile ordinarne altri separatamente.
2 unidades BF.423222 incluidas. Possibilidade de encomendar mais unidades individualmente.
2 unités BF.423222 inclus. Possibilité de commander à la pièce.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



SX

Patented

Max. 150°C



EXTERNAL SUPERIOR PLATE SEPARATOR

ES Separador Placas Superiores Externa DE Externe Obere Plattentrennung
 IT Separatore Piastre Superiori Esterno PT Separador Chapas Superior Externo FR Séparateur Plaque Supérieure Externe

INSTALLATION GUIDELINES


ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



EX

EX


● Cad Insertion Point





Max. 150°C

Max. 150°C

THREE PLATE MOLD APPLICATION



DOUBLE EJECTION APPLICATION




Ref.	A	B	C	D	E	F	G	H	J	K	L	L1	M	R	S	T	Min. Stroke	Max. Stroke	RF (N)	SW
EX.140600	62	40	20	48	26	9	14	22	ø4x14 (DIN6325)	10.5	348	13	5.5	7.2	M8	M6x30	4	250	4.000	5
EX.200800	84	54	27	66	36	12	20	30	ø6x20 (DIN7979)	13.5	348	17.5	7.5	9.2	M12	M8x40	5	250	9.000	6
EX.321200	126	84	42	102	60	20	32	46	ø10x30 (DIN7979)	18.5	530	27	11.5	12.5	M16	M12x65	8	375	20.000	10
EX.501600	174	120	60	140	86	26	50	64	ø12x40 (DIN7979)	25	530	40	15.5	17	M24	M16x90	10	375	40.000	14

PLATE ACCELERATOR

ES Elevador Placas DE Auswerferplatten-Beschleuniger
IT Acceleratore Piastra Espulsione PT Acelerador de Chapa FR Accélérateur Batterie d'Ejection

EP



Max. 150°C



Ref.	A	B	C	D	E	F	G	H max.	L max.	M	N	P	T	Max. Force	SW
EP.200813	20	8	13.2	25.8	9.4	11.4	5.9	11.6	4.4	5	15	Ø2.5x10	M3x12	125 kg.	2.5
EP.251016	25	10	16	32.3	11.8	14.3	7	15	5.7	6	18.5	Ø3x12	M4x16	250 kg.	3
EP.371522	37.5	15	22	48.5	17.7	21.5	10.5	23.5	9.1	8	25	Ø4x16	M6x25	350 kg.	5
EP.502030	50	20	30	64.6	23.6	28.6	14	32	12.5	10	34	Ø5x20	M8x30	800 kg.	6

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




DOUBLE EJECTION

ES Doble Expulsión DE Zweistufenauswerfer
IT Doppia Espulsione PT Dupla Extracção FR Double Ejection

DE

Max. 150°C





Ref.	CR(N)	SWa	SWb
DE.243648	3.800	5	8

! IMPORTANT

Use the scale to adjust the first opening from 5 to 30mm.
Utilice la escala para ajustar la primera carrera de 5 a 30 mm.
Verwenden Sie die Skala, um den ersten Hub von 5 bis 30mm. einzustellen.
Utilizzare la regolazione per impostare la prima corsa da 5 a 30mm.
Utilize a escala para definir o primeiro curso de 5 a 30mm.
Utilisez l'échelle pour régler la première course de 5 à 30mm.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




DY

REAR DOUBLE EJECTOR

ES Doble Expulsión Inferior DE Zweistufenauswerfer DY
IT Doppia Espulsione Inferiore PT Dupla extracção inferior FR Double Ejection inférieure



● Cad Insertion Point



Ref.	A	B	C	D	E	F	G	J	K	L	M	L1	L2	S
DY.142825	14	28	25	32	21	25	16	185	7.2	270	M6	48	49	83
DY.163230	16	32	30	36	24	28	18	252	8	337	M8	60	89	123

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



COMPACT DOUBLE EJECTION

ES Doble Expulsión Compacta DE Kompakter Zweistufenauswerfer
IT Doppia Espulsione Compatta PT Dupla Extração Compacta FR Double Ejection Compact



● Cad Insertion Point



IMPORTANT !
2 BF.503225 units included. More units could be ordered separately.
Se suministran 2 unidades de BF.503225. Se pueden pedir más unidades por separado.
2 St. BF.503225 enthalten. Mehr Einheiten können einzeln bestellt werden.
Vengono forniti 2 BF.503225. E' possibile ordinare altri separatamente.
2 unidades BF.503225 incluidas. Possibilidade de encomendar mais unidades individualmente.
2 unités BF.503225 inclus. Possibilité de commander à la pièce.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



SY


Patented

Max. 150°C

EXTERNAL DOUBLE EJECTION



ES Doble Expulsión Externa DE Externer Zweistufenauswerfer
 IT Doppia Espulsione Esterna PT Dupla Extração Externa FR Double Ejection Externe

● Cad Insertion Point



INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



Ref.	A	B	C	D	E	F	G	H	J	K	L	L1	M	R	S	T	Min. Stroke	Max. Stroke	RF (N)	SW
EY.140600	62	70	50	48	38	18	14	22	ø6x20	10.5	348	13	5.5	7.2	M8	M6x30	6	30	4.000	5
EY.200800	84	94	67	66	50	26	20	30	ø8x20	13.5	348	17.5	7.5	9.2	M12	M8x40	8	40	9.000	6
EY.321200	126	144	102	102	82	38	32	46	ø10x30	18.5	530	27	11.5	12.5	M16	M12x65	14	60	20.000	10
EY.501600	174	200	140	140	113	53	50	64	ø12x40	25	530	40	15.5	17	M24	M16x90	20	80	40.000	14

Max. 150°C

Max. 150°C

EXTERNAL SYNCHRONIZED PLATES



ES Sincronizador de Placas Externo DE Externe Plattensynchronisation
 IT Sincronizzatore di Piastre Esterno PT Sincronizador Chapas Externo Externa FR Synchronisation Mouvement Plaques

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation

EZ


EZ



Max. 150°C

Max. 150°C


Ref.	A	B	C	D	E	F	G	H	J	K	L	L1	M	N	P	Q	R	S	T	V	W	Min. Stroke	Max. Stroke	RF (N)	SW
EZ.140608	62	40	20	48	33	9	14	22	ø4x14 (DIN6325)	10.5	348	13	5.5	8	M5	30	7.2	M8	M6x30	300	20	4	250	4.000	5
EZ.200812	84	54	27	66	45	12	20	30	ø6x20 (DIN7979)	13.5	348	17.5	7.5	12	M8	42	9.2	M12	M8x40	300	25	5	250	9.000	6
EZ.321220	126	84	42	102	72	20	32	46	ø10x30 (DIN7979)	18.5	530	27	11.5	20	M12	65	12.5	M16	M12x65	450	42	8	375	20.000	10
EZ.501625	174	120	60	140	103	26	50	64	ø12x40 (DIN7979)	25	530	40	15.5	25	M16	92	17	M24	M16x90	450	60	10	375	40.000	14



EW

EX-EY-EZ ROD EXTENSION


ES Alargo EX-EY-EZ DE EX-EY-EZ Verlängerungsstange
IT Estensione EX-EY-EZ PT Extensor para EX-EY-EZ FR Extension pour EX-EY-EZ



CENTRAL ROD EXTENSION				
Ref.	G	L	S	Compatible with
EW.140033	14	330	M8	EX.14 / EY.14 / EZ.14
EW.200033	20	330	M12	EX.20 / EY.20 / EZ.20
EW.320049	32	495	M16	EX.32 / EY.32 / EZ.32
EW.500049	50	495	M24	EX.50 / EY.50 / EZ.50

LATERAL ROD EXTENSION				
Ref.	G	L	S	Compatible with
EW.140833	8	330	M5	EZ.14
EW.201233	12	330	M8	EZ.20
EW.322049	20	495	M12	EZ.32
EW.502549	25	495	M16	EZ.50


IMPORTANT !
Order 2 lateral rod extension for each EZ.
Pedir 2 extensiones laterales para cada EZ.
Bestellen Sie 2 seitliche Stangenverlängerung für jeden EZ.
Ordinare 2 estensioni laterali per ogni EZ.
Pedir 2 extensores laterales para cada EZ.
Demander 2 extension latérales pour chacune EZ.



Max. 150°C

ACCELERATED EJECTOR

ES Acelerador Expulsión DE Vorschub-Auswerfer
IT Acceleratore di Espulsione PT Acelerador de Extracção FR Accélérateur d'Éjection



Ref.	A	B	C	D	E	F	G	J	K	L	M	N	P	Q	R	CR (N)
AE.031620	3	16	20	12.5	22	13	14	8	32	22	17	37	-	4	3	1.800
AE.041620	4	16	20	12.5	22	13	14	8	32	22	17	37	-	4	3	1.800
AE.052430	5	24	30	16	34	16	20	15	44	36	27	57	2	4	3	2.800
AE.062430	6	24	30	16	34	16	20	15	44	36	27	57	2	4	3	3.800
AE.082430	8	24	30	17	34	17	20	15	44	36	27	57	2	4	3	4.700
AE.103036	10	30	36	21.5	40	21	28	20	62	46	34	78	2	6	4	6.400
AE.123036	12	30	36	21.5	40	21	28	20	62	46	34	78	2	6	4	7.600


IMPORTANT !
(* Possibility to key for using a curved ejector pin. (except AE.031620 & AE.041620)
(* Posibilidad de usar un anti giro para los expulsores con forma. (excepto AE.031620 & AE.041620)
(* Verdrehsicherung möglich für einen Auswerfer mit Kontur. (außer AE.031620 & AE.041620)
(* Possibilità di usare un antirrotazione per gli espulsori sagomati. (salvo AE.031620 & AE.041620)
(* Possibilidade de posicionar para extractores com perfil. (except AE.031620 & AE.041620)
(* Possibilité d'indexer l'éjecteur. (sauf AE.031620 & AE.041620)

Patented
Max. 150°C

EB


EX-EY-EZ EXTERNAL FIXING

ES Fijación Externa EX-EY-EZ DE EX-EY-EZ Externe Befestigung
IT EX-EY-EZ Fissaggio Esterno PT Fixação Externa EX-EY-EZ FR Fixation Externe pour EX-EY-EZ



CENTRAL EXTERNAL FIXING											
Ref.	A	B	C	K	H	M	S	SWa	SWb	T	Compatible with
EB.140020	24	50	30	10.5	22	5.5	M8x25	5	6	M6x30	EX.14 / EY.14 / EZ.14
EB.200025	34	60	38	13.5	30	7.5	M12x35	6	10	M8x40	EX.20 / EY.20 / EZ.20
EB.320042	50	86	52	18.5	46	11.5	M16x45	10	14	M12x65	EX.32 / EY.32 / EZ.32
EB.500060	66	100	64	25	64	15.5	M24x60	14	19	M16x90	EX.50 / EY.50 / EZ.50


LATERAL EXTERNAL FIXING											
Ref.	A	B	C	K	H	M	S	SWa	SWb	T	Compatible with
EB.140824	20	62	48	10.5	22	5.5	M5x20	5	4	M6x30	EZ.14
EB.201234	25	84	66	13.5	30	7.5	M8x25	6	6	M8x40	EZ.20
EB.322050	42	126	102	18.5	46	11.5	M12x50	10	10	M12x65	EZ.32
EB.502566	60	174	140	25	64	15.5	M16x60	14	14	M16x90	EZ.50



Max. 150°C

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



LR


THREADED LIMITER

ES Limitador con Rosca DE Auswerfer - Begrenzer mit Gewindeaufnahme
IT Limitatore Filettato PT Limitador com Rosca FR Limiteur avec Vis



Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



AL

THREADED LIMITER ADAPTER


ES Adaptador para Limitador Roscado DE Gewindeadapter
IT Adattatore per Limitatore Filettato PT Adaptador para Limitador Roscado FR Cadaptateur pour Limiteur avec Vis



Ref.	B	Compatible With
AL.0800M4	M4x10	LR.081620
AL.0800M5	M5x10	LR.081620
AL.0800M6	M6x10	LR.081620
AL.0800M8	M8x10	LR.081620

DOG LIFTER LIMITER

ES Limitador Patín DE Hubbegrenzer
IT Limitatore Pattino PT Limitador Patim Automático FR Limiteur



LD

Patented

Max. 150°C

Patented

Max. 150°C




BA-BE-BT

EJECTOR BASE

ES Base Expulsora DE Aufnahme für Auswerfer
IT Base Espulsore PT Base de Extractores FR Embases d'Ejection


● Cad Insertion Point



Ref.	A	B	C	D	CR (N)
BA.061418	6	14	18	3.5	≥ 3.800
BA.081620	8	16	20	5.5	≥ 4.700
BA.101822	10	18	22	7	≥ 6.400
BA.122024	12	20	24	9	≥ 7.600


Ref.	A	B	C	D	CR (N)
BT.061418	6	14	18	4.2	≥ 3.800
BT.081620	8	16	20	6.2	≥ 4.700
BT.101822	10	18	22	7	≥ 6.400
BT.122024	12	20	24	9	≥ 7.600

Ref.	A	B	C	CR (N)
BE.031115	3	11	15	≥ 1.800
BE.041216	4	12	16	≥ 1.800
BE.051317	5	13	17	≥ 2.800



Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



HEADLESS EJECTOR PIN

ES Varilla Expulsora DE Auswerfer ohne Kopf
IT Asta Espulsore PT Extractor sem Cabeça FR Ejecteur sans Tête

● Cad Insertion Point



IMPORTANT !
Indicate the desired **L** dimension after the reference.
Indicar la cota **L** necesaria después de la referencia.
Gewünschte Länge **L** angeben.
Indicare la quota **L** desiderata dopo il codice.
Indique a dimensão **L** desejada depois da referência.
Indiquer longueur **L** désirée après référence.

Ref.	A	L
VE.030...	3	600
VE.080...	8	800 1000
VE.100...	10	600 800

Patented


Max. 150°C

VE

HEADLESS EJECTOR SLEEVE

ES Tubular Expulsión DE Auswerferhülsen ohne Kopf
IT Espulsore Tubolare PT Extractor Tubular sem Cabeça FR Tubulaire sans Tête

● Cad Insertion Point



IMPORTANT !
Indicate the desired **L** dimension after the reference.
Indicar la cota **L** necesaria después de la referencia.
Gewünschte Länge **L** angeben.
Indicare la quota **L** desiderata dopo il codice.
Indique a dimensão **L** desejada depois da referência.
Indiquer longueur (**L**) désirée après référence.

Ref.	A	B	E	F	L
TE.063...	6	3	3.2	30	400 500 600 800
TE.106...	10	6	6.2	40	400 500 600 800
TE.128...	12	8	8.2	45	400 500 600 800

Patented

Max. 150°C


TE

DP

EJECTOR FOOT

ES Distanciator Placa DE Anschlagsscheibe
IT Distanziale Piastra PT Botão de Encosto FR Repos de Batterie

● Cad Insertion Point



Ref.	A	B	C	D
DP.200506	20	5	6.5	3.5
DP.250508	25	5	8.5	4.4
DP.280610	28	6	12	5.5




Max. 150°C

EJECTOR PLATE SPACER

ES Distanciator Placa DE Auswerferplatte Abstandhalter
IT Distanziale Piastra PT Espaçador de Chapas FR Entretoise de Passage

● Cad Insertion Point



Ref.	A
TR.204008	20
TR.404008	40

TR




Max. 150°C

TM

SAFETY STOPPER

ES Tope Magnético DE Abstandhalter Magnetisch
IT Blocco Magnetico PT Bloco Magnético FR Butée Magnétique

● Cad Insertion Point



Ref.	A
TM.102214	10
TM.122214	12.5
TM.152214	15
TM.202214	20




Max. 80°C

SHOCK ABSORBER

ES Tope Amortiguador DE Dämpfungsscheibe
IT Blocco Ammortizzante PT Batente Amortecedor FR Repos de Batterie avec Amortissement

● Cad Insertion Point



Ref.
TA.280806

IMPORTANT
Supplied only in bags of 4 units.
Suministrado en bolsas de 4 uds.
Verpackungseinheit 4 Stück.
Vendute in confezioni da 4 pezzi.
Fornecidos em sacos de 4 unidades.
Emballé en sac de 4 unités.


TA



Max. 150°C


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation





4

TRACEABILITY

TRACEABILITY INDEX

ÍNDICE TRAZABILIDAD / INHALTSVERZEICHNIS KENNZEICHNUNG
INDICE RINTRACCIABILITÀ / ÍNDICE RASTREABILIDADE / INDEX TRAÇABILITÉS

110/

Remote Date Stamp
Fechador Remoto
Ferngesteuerter Datumsteller
Datario Remoto
Remote Date Stamp
Dateur à Reglage Exterieur



110/

Remote Date Stamp Shaft Set
Conjunto Varilla para Fechador Remoto
Fernbedienbares Wellenset
Set Asta per Datario Remoto
Conjunto Transmissão para Datador Remoto
Jeu de Tige pour Changement d'Information



117/

Date Stamp Plus
Fechador Anual Plus
Datumsteller Plus
Datario Annuale Plus
Datador Anual Plus
Dateur Plus



117/

Removal Jig
Extractor Fechador
Abzieher für Datumsteller
Estrattore Datario
Extrator de Datador
Extracteur pour Dateur



110/

Remote Comand
Mando Remoto
Fernbedienbar
Comando Remoto
Comando Remoto
Commande à Distance



112/

Turning Key
Llave de Giro
Montageschlüssel
Chiave der Aggiornamento
Chave de Rotação
Clé de Changement d'Information



112/

Shaft Cutting Jig
Utili de Corte para la Varilla
Einstellungsvorrichtung Zum Ablängen
Utensile per Taglio Asta
Gabarito para Corte de Veio de Transmissão
Outil de Coupe pour les Tiges



118/

Xtra Date Stamp
Fechador Extra
Xtra Datumsteller
Datario Extra
Datador Extra
Dateur Extra



118/

Xtra Insert
Inserto Extra
Xtra Einsatz
Inserto Extra
Postiço Extra
Insert Extra



119/

Double Date Stamp
Fechador Doble
Zweifach-Datumstempel
Datario Doppio
Datador Duplo
Dateur Double



113/

Recycling Insert
Inserto Reciclaje
Recyclingeinsätze
Inserti di Riciclaggio
Indicadores de Reciclagem
Pion de Recyclage



113/

Mark Insert
Inserto Marca
Einsätze für Symbole
Inserto Simbolo
Postiço de Marcas
Insert de Marquage



120/

Temperature Dater
Fechador Temperatura
Datumsteller, wärmebeständig
Datario Temperatura
Datador Temperatura
Dateur Haute Température



120/

Temperature Insert
Inserto Temperatura
Einsätze, wärmebeständig
Inserto Temperatura
Indicador Temperatura
Insert Haute Température



114/

Interchangeable Insert
Inserto Intercambiable
Einsatz, austauschbar
Inserto Intercambiabile
Postiço Intermutável
Ensemble Interchangeable



114/

Turning Insert
Inserto Giratorio
Einsätze Drehbar
Inserto Girante
Postiço Giratório
Insert Tournant



115/

Unit Date Stamp
Fechador Unitario
Datumstellereinheit
Datario Unitario
Datador Unitário
Kit Mini Dateur



121/

Block Base
Base Monobloque
Aufnahme Datumblock
Base Monoblocco
Base Monoblocco
Multi Dateur



121/

Block Insert
Postiço Monobloque
Einsätze für Datumblöcke
Inserto Monoblocco
Postiço Monoblocco
Inserts Multi Dateur



122/

Cycle Counter
Contador Ciclos
Zählwerk
Conta Cicli
Contador de Ciclos
Compteur de Cycle



116/

Date Stamp
Fechador Anual
Datumsteller
Datario Annuale
Datador Anual
Corps Dateur



116/

Date Insert
Inserto Anual
Einsätze für Datumsteller
Inserto Datario
Indicador Anual
Insert Dateur




FR



REMOTE DATE STAMP

ES Fechador Remoto DE Ferngesteuerter Datumssteller
IT Datario Remoto PT Datador Remoto FR Dateur à Reglage Extérieur

● Cad Insertion Point



	3 Shifts	31 Days	12 Months	10 Years	A
Raised lettering	FR.08HR03	FR.08HR31	FR.08HR12	FR.08HR10-..	8
	FR.12HR03	FR.12HR31	FR.12HR12	FR.12HR10-..	12
Recessed lettering	FR.08LR03	FR.08LR31	FR.08LR12	FR.08LR10-..	8
	FR.12LR03	FR.12LR31	FR.12LR12	FR.12LR10-..	12

IMPORTANT ! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

Patented




CF

REMOTE DATE STAMP SHAFT SET

ES Conjunto Varilla para Fechador Remoto DE Fernbedienbares Wellenset IT Set Asta per Datario Remoto
PT Conjunto de Transmissão para Datador Remoto FR Jeu de Tige pour Changement d'Information

● Cad Insertion Point



Ref.	L	M	R	S	T	U	W
CF.060600	600	500	25	30	40	45	40
CF.061200	1200	1100	40	50	60	60	60

*Special for extensions


Max. 150°C

MN


REMOTE COMMAND

ES Mando Remoto DE Fernbedienbar
IT Comando Remoto PT Comando Remoto FR commande à Distance

● Cad Insertion Point




Ref.	# of Positions
MN.202003	3 (Shifts)
MN.202010	10 (Years)
MN.202012	12 (Months)
MN.202031	31 (Days)






Max. 150°C

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



FR





TK




TURNING KEY
 ES Llave de Giro DE Montageschlüssel
 IT Chiave per Aggiornamento PT Chave de Rotação FR Clé de Changement d'Information

TURNING KEY SUPPORT




TURNING KEY




Ref. TK.412903

● Cad Insertion Point

Warehouse and transport position
 Posición en almacén y durante el transporte
 Werkzeuglager- und Transportposition
 Posizione in magazzino e durante il trasporto
 Posição de molde em armazém
 Position lors du stockage et du transport





Molding position
 Posición en producción
 Werkzeugpositionfixierung
 Posizione di stampaggio
 Posição de molde em injeção
 Position lors de la production



Installation Guidelines



Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




CT



SHAFT CUTTING JIG
 ES Util de Corte para la Varilla DE Einstellvorrichtung Zum Ablängen
 IT Utensile per Taglio Asta PT Gabarito para Corte de Veio de Transmissão FR Outil de Coupe Pour les Tiges



Ref. CT.601212



FLEXIBLE SHAFT




RECYCLING INSERT

ES Inserto Reciclaje DE Recyclingeinsätze
 IT Inserti di Riciclaggio PT Indicadores de Reciclagem FR Pion de Recyclage



IR

● Cad Insertion Point





Ref.	A	B	E	H	K	S
IR.1012..	10	12	8	7	1.5	5.6
IR.1212..	12	12	10	7	1.8	6.8
IR.1616..	16	16	12	9	2.4	9
IR.2016..	20	16	16	9	3.2	11.5

IMPORTANT !
 Indicate the model after the reference.
 Indicar el modelo después de la referencia.
 Wählen Sie den Typ entsprechend der Referenz.
 Indicare il modello dopo il codice.
 Indicar o modelo depois da referência.
 Indiquer le sigle après la référence.

MARK INSERT

ES Inserto Marca DE Einsätze für Symbole
 IT Inserto Simbolo PT Postiço de Marcas FR Insert de Marquage

● Cad Insertion Point




IM

Ref.	Blank Ref.	A	B	E	H
IM.041000	IM.041000-BLANK	4	10	2	6
IM.051000	IM.051000-BLANK	5	10	3	6
IM.061000	IM.061000-BLANK	6	10	4	6
IM.081200	IM.081200-BLANK	8	12	6	7
IM.101200	IM.101200-BLANK	10	12	8	7
IM.121200	IM.121200-BLANK	12	12	10	7
IM.161600	IM.161600-BLANK	16	16	12	9
IM.201600	IM.201600-BLANK	20	16	16	9

IMPORTANT !
 Send DXF file with your design.
 Envíenos un archivo DXF con su diseño.
 Senden Sie als DXF File.
 Inviare un file DXF con il disegno dell'incisione richiesta.
 Envie-nos um ficheiro em DXF com o seu desenho.
 Envoyez nous le fichier DXF du dessin.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation





Max. 150°C

INTERCHANGEABLE INSERT

ES Inserto Intercambiable DE Einsätze Austauschbar
IT Inserto Intercambiabile PT Postiço Intermutável FR Ensemble Interchangeable

● Cad Insertion Point

BI+II



Ref.	A	E	Ref.	Blank Ref.
BI.101209	10	6	II.101203	II.101203-BLANK
BI.121209	12	8	II.121203	II.121203-BLANK
BI.161209	16	10	II.161203	II.161203-BLANK


IMPORTANT! Send DXF file with your design.
Envíenos un archivo DXF con su diseño.
Senden Sie als DXF File.
Inviare un file DXF con il disegno dell'incisione richiesta.
Envie-nos um ficheiro em DXF com o seu desenho.
Envoyez nous le fichier DXF du dessin.

UNIT DATE STAMP


ES Fechador Unitario DE Datumstellereinheit
IT Datario Unitario PT Datador Unitário FR Kit Mini Dateur

● Cad Insertion Point

FU+IU




Supplied also with UM / Entregado también con el UM / UM im Lieferumfang enthalten
Fornito con il particolare UM / Também fornecido como UM / Fournis avec unité de montage UM



Patented
Max. 150°C

TURNING INSERT

ES Inserto Giratorio DE Einsätze Drehbar
IT Inserto Girante PT Postiço Giratório FR Insert Tournant




Ref.	A
IG.101203	10
IG.121203	12
IG.161203	16

IG

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Engrave on the mould.

ES Grabar en el molde.
DE Gravur an der Form.
IT Incidere sullo stampo.
PT Gravar no molde.
FR Gravure sur le moule.

Year change.

ES Cambio de año.
DE Jahreswechsel.
IT Cambio dell'anno.
PT Mudança de ano.
FR Changement de l'année.






FA

DATE STAMP

ES Fechador Anual DE Datumsteller
IT Datario Annuale PT Datador Anual FR Corps Dateur

● Cad Insertion Point



Patented
Max. 150°C

IMPORTANT ! Special engraving available under request.
Grabados especiales bajo demanda.
Andere Gravuren auf Anfrage.
Incisioni speciali su richiesta.
Gravações especiais por encomenda.
Gravure spéciale par commande.


IMPORTANT ! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

	31 Days	12 Months	12 Months+Year	Years	Blank	A	C	D	E	L	N
-	FA.0422SF	FA.042212-..	FA.042204-..	FA.042200	4	2.2	6	3.5	12	4	
-	FA.0530SF	FA.053012-..	FA.053004-..	FA.053000	5	3	6	3.5	12	4	
FA.063231	FA.0632SF	FA.063212-..	FA.063205-..	FA.063200	6	3.2	12	4	20	5	
FA.084731	FA.0847SF	FA.084712-..	FA.084705-..	FA.084700	8	4.7	12	6	20	5	
FA.105731	FA.1057SF	FA.105712-..	FA.105706-..	FA.105700	10	5.7	12	8	20	6	
FA.126731	FA.1267SF	FA.126712-..	FA.126708-..	FA.126700	12	6.7	12	10	20	8	
FA.168731	FA.1687SF	FA.168712-..	FA.168710-..	FA.168700	16	8.7	12	12	20	10	
FA.200731	FA.2007SF	FA.200712-..	FA.200710-..	FA.200700	20	10.7	12	14	20	10	

DATE STAMP PLUS

ES Fechador Anual Plus DE Datumsteller Plus
IT Datario Annuale Plus PT Datador Anual Plus FR Dateur Plus

● Cad Insertion Point



FP

Patented
Max. 150°C

IMPORTANT ! Special engraving available under request.
Grabados especiales bajo demanda.
Andere Gravuren auf Anfrage.
Incisioni speciali su richiesta.
Gravações especiais por encomenda.
Gravure spéciale par commande.


IMPORTANT ! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

	31 Days	12 Months	12 Months+ Year	Years	Blank	A	C	D	L	N
-	FP.0422SF	FP.042212-..	FP.042204-..	FP.042200	4	2.2	5.5	12	4	
-	FP.0530SF	FP.053012-..	FP.053004-..	FP.053000	5	3	5.5	12	4	
FP.063231	FP.0632SF	FP.063212-..	FP.063205-..	FP.063200	6	3.2	8	20	5	
FP.084731	FP.0847SF	FP.084712-..	FP.084705-..	FP.084700	8	4.7	8	20	5	
FP.105731	FP.1057SF	FP.105712-..	FP.105706-..	FP.105700	10	5.7	8	20	6	
FP.126731	FP.1267SF	FP.126712-..	FP.126708-..	FP.126700	12	6.7	8	20	8	
FP.168731	FP.1687SF	FP.168712-..	FP.168710-..	FP.168700	16	8.7	8	20	10	
FP.200731	FP.2007SF	FP.200712-..	FP.200710-..	FP.200700	20	10.7	8	20	10	

IA

DATE INSERT

ES Inserto Anual DE Einsätze für Datumsteller
IT Inserto Datario PT Indicador Anual FR Insert Dateur




Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione
Instruções de Instalação · Mode d'Installation

Replacement for FA and FP


Arrow Only	Year	C	M
IA.2275SF	IA.2275..	2.2	8.1
IA.3075SF	IA.3075..	3	8.1
IA.3217SF	IA.3217..	3.2	17
IA.4717SF	IA.4717..	4.7	17
IA.5717SF	IA.5717..	5.7	17
IA.6717SF	IA.6717..	6.7	17
IA.8717SF	IA.8717..	8.7	17
IA.1007SF	IA.1007..	10.7	17



Max. 150°C

REMOVAL JIG


ES Extractor Fechador DE Abzieher für Datumsteller
IT Estrattore Datario PT Extrator de Datador FR Extracteur pour Dateur



Ref.	Compatible with
EF.322405-SET	FP.xxxxxx

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



FX

XTRA DATE STAMP

ES Fechador Extra DE Xtra Datumsteller
IT Datario Extra PT Datador Extra FR Dateur Extra


DOUBLE DATE STAMP

ES Fechador Doble DE Zweifach-Datumstempel
IT Datario Doppio PT Datador Duplo FR Dateur Double

FD



Patented
Max. 150°C



IMPORTANT! Special engraving available under request.
Grabados especiales bajo demanda.
Andere Gravuren auf Anfrage.
Incisioni speciali su richiesta.
Gravações especiais por encomenda.
Gravure spéciale par commande.


IMPORTANT! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

	31 Days	12 Months	12 Months+Year	Years	Blank	A	C	E	F	L	N	S
-	FX.0421SF	FX.042112-..	FX.042104-..	FX.042100	4	2.1	2	1.6	5	4	0.25	
-	FX.0531SF	FX.053112-..	FX.053104-..	FX.053100	5	3.1	2.5	2.5	8	4	0.2	
FX.063231	FX.0632SF	FX.063212-..	FX.063205-..	FX.063200	6	3.2	4	6	16	5	0.25	
FX.084731	FX.0847SF	FX.084712-..	FX.084705-..	FX.084700	8	4.7	6	6	16	5	0.25	
FX.105731	FX.1057SF	FX.105712-..	FX.105706-..	FX.105700	10	5.7	8	6	16	6	0.35	
FX.126731	FX.1267SF	FX.126712-..	FX.126708-..	FX.126700	12	6.7	10	6	16	8	0.35	

XTRA INSERT


ES Inserto Extra DE Xtra Einsatz
IT Inserto extra PT Postiço Extra FR Insert Extra

IX




Arrow only	Annual	C	M
IX.2148SF	IX.2148..	2.1	4.8
IX.3178SF	IX.3178..	3.1	7.8
IX.3215SF	IX.3215..	3.2	15.5
IX.4715SF	IX.4715..	4.7	15.5
IX.5715SF	IX.5715..	5.7	15.5
IX.6715SF	IX.6715..	6.7	15.5

Installation Guidelines
Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione
Instruções de Instalação · Mode d'Installation



IMPORTANT! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

● Cad Insertion Point





12 Month+Year	Blank	A	B	C	E	N
FD.080512-..	FD.080500	8	5.5	3	6	5
FD.120812-..	FD.120800	12	8	4	10	6
FD.161012-..	FD.161000	16	10.5	5.3	12	10

IMPORTANT! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

IMPORTANT! Special engraving available under request.
Grabados especiales bajo demanda.
Andere Gravuren auf Anfrage.
Incisioni speciali su richiesta.
Gravações especiais por encomenda.
Gravure spéciale par commande.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




FT

TEMPERATURE DATER

ES Fechador Temperatura DE Datumsteller Wärmebeständig
IT Datario Temperatura PT Datador Temperatura FR Dateur Haute Température

● Cad Insertion Point



31 Days	12 Months	12 Month+Year	Years	Blank	A	B	C	D	N
FT.084731	FT.0847SF	FT.084712-..	FT.084705-..	FT.084700	8	12	4.7	11	5
FT.126731	FT.1267SF	FT.126712-..	FT.126708-..	FT.126700	12	16	6.7	12	8


IMPORTANT! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence du produit.

! N = # of years

BLOCK BASE

ES Base Monobloque DE Aufnahme Datumsblock
IT Base Monoblocco PT Base Monoblocco FR Multi Dateur

● Cad Insertion Point



Ref.	A	C	E	#PM
BM.160603	16	6.5	8	3
BM.180604	18	6.5	8	4
BM.220903	22	8.8	10	3
BM.250904	25	8.8	10	4
BM.281103	28	11.5	12	3
BM.321104	32	11.5	12	4

IMPORTANT! Select separately the 3 or 4 PM needed.
Seleccionar los 3 o 4 PM's requeridos.
3 oder 4 Stück PM mitbestellen.
Specificare i 3 o 4 inserti PM desiderati.
Pedir os 3 ou 4 PM necessários.
Demander les 3 ou 4 inserts PM nécessaires.

BM


Patented
Max. 150°C

IT

TEMPERATURE INSERT

ES Inserto Temperatura DE Einsätze Wärmebeständig
IT Inserto Temperatura PT Indicador Temperatura FR Insert Haute Température

● Cad Insertion Point




Arrow only	Year	C
IT.4719SF	IT.4719..	4.7
IT.6719SF	IT.6719..	6.7

IMPORTANT! Indicate the year after the reference.
Indicar el año después de la referencia.
Geben Sie das Jahr nach dem Verweis an.
Indicare l'anno dopo il codice.
Indicar o ano depois da referência.
Indiquer l'année après la référence.

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



BLOCK INSERT

ES Postizo Monobloque DE Einsätze für Datumsblöcke
IT Inserto Monoblocco PT Postiço Monoblocco FR Inserts Multi Dateur

● Cad Insertion Point




Ref.	C
PM.0615-...	6.5
PM.0915-...	8.8
PM.1115-...	11.5

IMPORTANT! Special engraving available under request.
Grabados especiales bajo demanda.
Andere Gravuren auf Anfrage.
Incisioni speciali su richiesta.
Gravações especiais por encomenda.
Gravure spéciale par commande.

Logos						Inserts					
00	01	02	03	04	05	SF	101	102	103	104	105
06	07	08	09	10	11	106	107	108	109	110	111

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Patented
Max. 150°C

CC

CYCLE COUNTER

ES Contador Ciclos DE Zählwerk
IT Conta Cicli PT Contador de Ciclos FR Compteur de Cycle

● Cad Insertion Point




- | | | | | |
|--|--|--|--|---|
| <p>1
Security Switch.
ES Interruptor de Seguridad.
DE Sicherheitskontakt.
IT Interruttore di Sicurezza.
PT Interruptor de Segurança.
FR Interrupteur Sécurité.</p> | <p>2
Magnetic Fixing.
ES Fijación Magnética.
DE Magnetbefestigung.
IT Fissaggio Magnetico.
PT Fixação Magnética.
FR Fixation Magnétique.</p> | <p>3
Total + Partial.
ES Total + Parcial.
DE Gesamt + Teilmenge.
IT Totale + Parziale.
PT Total + Parcial.
FR Total + Partiel.</p> | <p>4
Unique Part Number.
ES Número Único de Identificación.
DE Identifikationsnummer.
IT Numero Unico di Identificazione.
PT Numero Único de Identificação.
FR Identification par Numéro Unique.</p> | <p>5
IC Position Indicator.
ES Indicador de Posición IC.
DE Positionsanzeiger IC.
IT Indicatore di Posizione IC.
PT Indicador de Posição IC.
FR Indicateur Position IC.</p> |
|--|--|--|--|---|

Ref.	Cycles / Min	Replaceable Battery
CC.HS5328	Up to 500	ER 14250 ½ AA

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Patented
Max. 60°C



5

VACUUM

VACUUMJET SYSTEM INDEX

ÍNDICE SIETEMA DE VACÍO / INHALTSVERZEICHNIS VACUUMJET-SYSTEM
 INDICE SISTEMA VACUUM JET / ÍNDICE SISTEMA DE VÁCUO / INDEX SISTÈME DE VIDE

132/

Double Action Vacuumjet
 Unidad de Vacío de Doble Acción
 Double Action Vacuumjetsystem
 Vacuumjet Doppia Azione
 Vacuumjet Duplo Efeito
 Vacuumjet Double Effet



134/

Smart Vacuumjet
 Vacuumjet Intelligente
 Smart Vacuumjetsystems
 Smart Vacuumjet
 Vacuumjet Intelligente
 Vacuumjet Intelligent



136/

Vacuumjet Unit
 Unidad de Vacío (Vacuumjet)
 Vacuumjet Steuereinheit
 Vacuumjet
 Vacuumjet Unidade de Vácuo (Vacuumjet)
 Unité de Vide



138/

Vacuumjet +
 Unidad de Vacío (Vacuumjet +)
 Vacuumjet +
 Vacuumjet +
 Vacuumjet +
 Unidade de Vácuo (Vacuumjet +)
 Unité de Vide (Vacuumjet +)



140/

Vacuum Control
 Controlador Vacuumjet
 Vacuum Regeleinheit
 Unità di controllo Vacuum
 Controlador Vacuumjet
 Contrôle Vacuumje



142/

Vacuumjet Valve
 Válvula Vacuumjet
 Vacuumjet Ventil
 Valvola Vacuumjet
 Válvula Vacuumjet
 Soupape Vacuumjet



142/

Vacuumjet Valve Tube
 Tubo Válvula Vacuumjet
 Vacuumjet Ventilrohr
 Tubo Valvola Vacuumjet
 Tubo Válvula Vacuumjet
 Tube soupape Vacuumjet



143/

Pneumatic Piston
 Pistón Neumático
 Pneumatikkolben
 Pistone Pneumatico
 Pistom Pneumático
 Piston Pneumatique



143/

Pneumatic Piston
 Pistón Neumático
 Pneumatikkolben
 Pistone Pneumatico
 Pistom Pneumático
 Piston Pneumatique



144/

Spiral Ejector
 Expulsor en Espiral
 Spiral Auswerfer
 Espulsore con Spirale
 Extractor com Espiral
 Ejecteur avec Spirale



144/

Non-rotating Head for Ejector Pins
 Base Anti-rotación para Expulsores
 Verdrehgesicherter Kopf
 Base Anti-Giro per Espulsori
 Cabeça Anti-Rotativa Embasses
 Anti-Rotation pour Éjecteurs



145/

Spiral Sleeve
 Tubular en Espiral
 Spiral Hülse
 Espulsore con Spirale
 Tubular com Espiral
 Ejecteur Avec spirale



145/

Keyed Tubular Base
 Base Anti-rotación para Tubulares
 Hülsenaufnahme Verdreh Gesichert
 Base Anti-giro per Cannocchiali
 Base Anti-rotação para Tubulares
 Embasses Anti-Rotation pour Tubulaires



146/

Ejectors
 Expulsores
 Auswerfer
 Espulsori
 Extractores
 Éjecteurs



146/

Vacuumjet Plug
 Casquillo Vacuumjet
 Vacuumjet Dichtstopfen
 Bussola Vacuumjet
 Casquillo Vacuumjet
 Bague Vacuumjet



147/

Laminar Gas Vent
 Salida de Gases Laminar
 Laminargasventil
 Usctia dei Gas Laminare
 Postiço de Ventilação Laminar
 Eventation Laminare



148 /

Connection Tube
 Tubo Conexión
 Verbindungsrohr
 Tubo Connessione
 Tubo de Ligação
 Tube de Connexion



148/

Vacuumjet Seal
 Sello Vacuumjet
 Vacuumjet Dichtschnur
 Guarnizione Vacuumjet
 Vedante Vacuumjet
 Joint Vacuumjet



WHAT DOES VACUUM STAND FOR?

To vacuum is to remove the air out of a space, therefore, leaving this space completely empty, creating a negative pressure.

WHY IS IT INTERESTING TO CREATE A VACUUM INSIDE MOLDS?

During the injection process there is an invisible pressure within the cavity, making it difficult to fill, this pressure is the air! The air is cornered, compressed and heated by plastic, and is pushed outside the mold through its clearances, complicating therefore the cavity filling, and creating problems in the process, in the plastic part and slowing down the cycle time.

¡We need to extract the air from the cavity or at least minimize its influence in the process!

HOW CAN WE EXTRACT THE AIR?

CUMSA has developed a series of products to enable the vacuuming of mold cavities. Discover these products in this catalogue!

From just 20-30% of vacuum created, improvements in the process can be observed; therefore, it is important to balance the level of vacuum with the time needed, to find the best option to suit your particular needs.

WHAT BENEFITS COULD MY MOLD ACHIEVE WITH THE VACUUM?

In the injected plastic part:

- Superior visual appearance (less sink marks).
- Dimensional stability (less weld lines).
- Uniform color.
- High mechanical resistance due to perfect plastic distribution.

In the process:

- Reduced cycle time.
- Lower injection temperature & pressure.
- Increase in production.


WHAT IS NEEDED TO CREATE THE VACUUM?

- Complete sealing of the mold to achieve optimal vacuum results.
- 1 or 2 electrovalves, depending on the model selected.
- No need of any additional vacuum pump/mechanism.

MOLD CLOSED

With the mold closed, air is trapped inside the cavity. If injection starts, the air will be cornered, heated and compressed by the plastic, producing poor quality plastic parts.

We have to create vacuum!




CREATING THE VACUUM IN THE CAVITY

To optimize the injection process we have to take out the air from the cavity.

There are several methods to accomplish this, but in all of them it is the injected plastic that pushes out the air. With VACUUMJET, when it is activated prior to the injection, a valve is opened and the air is vacuumed, therefore, leaving the cavity in optimal conditions for injection.

→ Air Flow




INJECTION STARTS

The VACUUMJET continues sucking the air during all the injection process, to guarantee the maximum ease of the plastics fluidity, therefore reducing the pressure needed.

EJECTION PROCESS

When the injection is finished, the VACUUMJET stops, and as with all molds, the plastic is cooled and the part is ejected...but with the VACUUMJET system, we obtain greater quality plastic part, with at least the same injection time, if not faster, and without altering the optimal injection parameters.



VACUUMJET SYSTEM by CUMSA

WICH PRODUCT IS THE BEST FOR MY MOLD?

DO I NEED TO CONTROL THE VACUUM LEVEL?	YES			
DO I HAVE SPACE FOR A VACUUM VALVE?	YES		NO	
DO I NEED REVERSE BLOWING?	YES	NO	YES	NO
HOW MANY ELECTROVALVES DO I NEED?	2  SV	2  VM + VJ	2  VM + VB	1  VM + VG

The Vacuumjet + (VG model) can be added to any combination to increase vacuuming power and speed up the vacuum process. For each VG model, a separate compressed air circuit is needed to assure that we always have at least 6 BARS of air pressure.

NO				DO I NEED TO CONTROL THE VACUUM LEVEL?
YES		NO		DO I HAVE SPACE FOR A VACUUM VALVE?
YES	NO	YES	NO	DO I NEED REVERSE BLOWING?
3  VJ + VB	2  VJ	2  VB	1  VG	HOW MANY ELECTROVALVES DO I NEED?

The use of Spiral Ejector or Spiral Sleeve (VP & VS) is mandatory when not using a valve. However, it is also recommended when using a valve to maintain the vacuum achieved throughout the rest of the process.

DOUBLE ACTION VACUUMJET

ES Unidad de Vacío de Doble Acción DE Double Action Vacuumjetsystem
 IT Vacuumjet Doppia Azione PT Vacuumjet Duplo Efeito FR Vacuumjet Double Effet

INSTALLATION GUIDELINES


ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



VB

VB




● Cad Insertion Point



Ref.	Supply Pressure	Max. Vacuum	Max. Flow	Consumption
VB.607638	5-6 BAR	-900 mbar	75 L./ Min.	60 L./ Min.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Patented

Max. 80°C

Vacuum

Blow-off

SV

SMART VACUUMJET


ES Vacuumjet Inteligente DE Smart Vacuumjetsystems
IT Smart Vacuumjet PT Vacuumjet Inteligente FR Vacuumjet

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation




SV




Ref.	Supply Pressure	Max. Vacuum	Max. Flow	Consumption
SV.605253	5-6 BAR	-900 mbar	75 L./ Min.	60 L./ Min.

Installation Guidelines




Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Vacuum / Blow-off Section



Vacuum Section



Patented

Max. 80°C

Vacuum

Blow-off

VACUUMJET UNIT

ES Unidad de Vacío (Vacuumjet) DE Vacuumjet Steuereinheit
 IT Vacuumjet PT Unidade de Vácuo (Vacuumjet) FR Unité de Vide

INSTALLATION GUIDELINES


ES Consejos de Instalación DE Richtlinien zur Installation
 IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation

VJ

VJ





● Cad Insertion Point



Ref.	Supply Pressure	Max. Vacuum	Max. Flow	Consumption
VJ.600000	5-6 BAR	-900 mbar	75 L./ Min.	60 L./ Min.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Patented


Max. 80°C

Vacuum

Compressed air

VACUUMJET +

ES Unidad de Vacío + (Vacuumjet+) DE Vacuumjet +
IT Vacuumjet + PT Unidade de Vácuo (Vacuumjet+) FR Unité de Vide (Vacuumjet+)




Ref.	Supply Pressure	Max. Vacuum	Max. Flow	Consumption
VG.523016	5-6 BAR	-900 mbar	75 L./ Min.	60 L./ Min.

IMPORTANT Several units can be connected together in the same Vacuum circuit.
En un solo circuito de vacío se pueden conectar varias unidades.
Mehrere Einheiten können zusammen im gleichen Vakuumkreislauf angeschlossen werden.
In un solo circuito si possono collegare diverse unità.
Em apenas um circuito de ar podemos ligar varias unidades.
Avec un seul circuit d'air nous pouvons relier plusieurs unités.


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



Patented

Max. 80°C

Vacuum

VACUUM CONTROL

ES Controlador Vacuumjet DE Vacuum Regeleinheit
IT Unità di Controllo Vacuum PT Controlador Vacuumjet FR Contrôle Vacuumjet

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation





VM

VM

Patented
Max. 80°C


Patented
Max. 80°C



Vacuum
Compressed air

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




WW



VACUUMJET VALVE

ES Válvula Vacuumjet DE Vacuumjet Ventil
IT Valvola Vacuumjet PT Válvula Vacuumjet FR Soupape Vacuumjet

● Cad Insertion Point




Ref.	A	B	C	D	E
W.086414	8	6.7	10	6.5	14
W.121014	12	9.8	10	10	14
W.161416	16	14	10	10	16

Patented




VT



VACUUMJET VALVE TUBE


ES Tubo Válvula Vacuumjet DE Vacuumjet Ventilrohr
IT Tubo Valvola Vacuumje PT Tubo Válvula Vacuumjet FR Tube soupape Vacuumjet



Ref.	L
VT.043209	209
VT.043500	500

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Patented



PNEUMATIC PISTON

ES Pistón Neumático DE Pneumatikkolben
IT Pistone Pneumatico PT Pistom Pneumático FR Piston Pneumatique

● Cad Insertion Point



IMPORTANT

PA must be ordered separately.
La referencia PA debe pedirse por separado.
PA bitte separat bestellen.
Il codice PA deve essere ordinato separatamente.
O PA deve ser encomendado em separado.
PA doit être commandée séparément.


PT+PA

Patented



Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



PNEUMATIC PISTON

ES Pistón Neumático DE Pneumatikkolben
IT Pistone Pneumatico PT Pistom Pneumático FR Piston Pneumatique

● Cad Insertion Point



PT

Patented




VP

SPIRAL EJECTOR

ES Expulsor en Espiral DE Spiral Auswerfer
IT Espulsore con Spirale PT Extractor com Espiral FR Ejecteur avec Spiral

● Cad Insertion Point



Ref.	A	L	
VP.060527-...	6	150	250 350
VP.080527-...	8	150	250 350
VP.100530-...	10	150	250 350
VP.120530-...	12	150	250 350

IMPORTANT ! Indicate the desired **L** dimension after the reference.
Indicar al final de la referencia, la cota **L** deseada.
Gewünschte Länge **L** angeben.
Indicare la quota **L** desiderata alla fine del codice.
Indique o dimensão **L** desejada depois da referência.
Préciser le début de référence et le compléter par la dimension **L** souhaitée.


Patented
Max. 150°C

VS

SPIRAL SLEEVE

ES Tubular en Espiral DE Spiral Hülse
IT Espulsore con Spirale PT Tubular com Espiral FR Ejecteur avec Spiral

● Cad Insertion Point



Ref.	A	B	C	L	
VS.030060-...	3	6	3.2	150	250 350
VS.050080-...	5	8	5.2	150	250 350
VS.060100-...	6	10	6.2	150	250 350
VS.080120-...	8	12	8.2	150	250 350

IMPORTANT ! Indicate the desired **L** dimension after the reference.
Indicar al final de la referencia, la cota **L** deseada.
Gewünschte Länge **L** angeben.
Indicare la quota **L** desiderata alla fine del codice.
Indique o dimensão **L** desejada depois da referência.
Préciser le début de référence et le compléter par la dimension **L** souhaitée.


Patented
Max. 150°C

NP

NON-ROTATING HEAD FOR EJECTOR PINS

ES Base Anti-Rotación para Expulsores DE Verdrehgesicherter Kopf
IT Base Anti-Giro per Espulsori PT Cabeça Anti-Rotativa FR Embasses Anti-Rotation pour Éjecteurs


● Cad Insertion Point



Ref.	A	N	P	Q	T	CR(N)
NP.030908	3.2	9	8	2	M4	4.000
NP.050908	5.2	9	8	3.5	M4	8.000
NP.061108	6.2	11	11	4	M5	9.000
NP.081108	8.1	11	11	5.5	M5	12.000

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



Max. 150°C


NR

KEYED TUBULAR BASE

ES Base Anti-Rotación para Tubulares DE Hülsenaufnahme Verdreh Gesichert
IT Base anti-Giro per Cannocchiali PT Base Anti-Rotação para Tubulares FR Embasses Anti-Rotation pour Tubulaires


● Cad Insertion Point

Ref.	A	N	P	Q	CR (N)
NR.061208	6.1	12	4	4	8.000
NR.081408	8.1	14	4.5	5.5	11.000
NR.101608	10.1	16	5.5	7.5	13.000
NR.122008	12.1	20	6.5	9.5	16.000



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Max. 150°C

PH

EJECTORS

ES Expulsores DE Auswerfer
IT Espulsori PT Extractores FR Ejecteurs



Ref.	A	L
PH.130000-...	3	250 330 500
PH.150000-...	5	250 330 500
PH.160000-...	6	250 330 500
PH.180000-...	8	250 330 500


IMPORTANT !
Indicate the desired **L** dimension after the reference.
Indicar al final de la referencia, la cota **L** deseada.
Gewünschte Länge **L** angeben.
Indicare la quota **L** desiderata alla fine del codice.
Indique o dimensão **L** desejada depois da referência.
Préciser le début de référence et le compléter par la dimension **L** souhaitée.

Max. 150°C

LAMINAR GAS VENT

ES Salida de Gases Laminar DE Laminargasventil
IT Uscita dei Gas Laminare PT Postiço de Ventilação Laminar FR Eventation Laminaire

● Cad Insertion Point



LV


Max. 150°C

CV

VACUUMJET PLUG

ES Casquillo Vacuumjet DE Vacuumjet Dichtstopfen
IT Bussola Vacuumjet PT Casquilho Vacuumjet FR Bague Vacuumjet


● Cad Insertion Point



Ref.	A	B	C	D	E	F	T
CV.020812	2	8	12	4.5	8	2x1.5	M3
CV.030812	3	8	12	4.5	8	3x1.5	M4
CV.041012	4	10	12	4.5	8	4x1.5	M5
CV.051012	5	10	12	4.5	8	5x1.5	M6
CV.061212	6	12	12	4.5	8	6x1.5	M8
CV.081416	8	14	16	7	10	8x2	M10
CV.101616	10	16	16	7	10	10x2	M12
CV.121816	12	18	16	7	10	12x2	1/4 GAS

Installation Guidelines



Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Ref.	A	B	F
CV.142006	14	20	14x2
CV.162206	16	22	16x2
CV.202606	20	26	20x2

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



IMPORTANT !




The LV can only be machined by using EDM.
El LV sólo se puede mecanizar usando electroerosión.
Das LV kann nur mit Hilfe von EDM bearbeitet werden.
L'LV può essere lavorato solo tramite elettroerosione.
Para maquinar o LV, utilizar apenas EDM (erosão).
Le LV ne peut être usiné qu'en utilisant l'électroérosion.

JV

VACUUMJET SEAL

ES Sello Vacuumjet DE Vacuumjet Dichtschnur
IT Guarnizione Vacuumjet PT Vedante Vacuumjet FR Joint Vacuumjet


● Cad Insertion Point



Ref.	A	B	C	mm
JV.030200	3	2.2	2.7	2.000
JV.050200	5	3.8	4.2	2.000

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




IMPORTANT !
Ensure joint is sealed using silicon.
Sellar con silicona la entrada de herramienta.
Dichtschnur an den Enden mit Silikon verkleben.
Sigillare con silicone l'entrata dell'utensile.
Vedar a linha de junta.
Coller ensemble les extrémités du joint.

Patented
Max. 200°C

ST SEAL TOOL



Ref.	Compatible with
ST.030200	JV.030200
ST.050200	JV.050200



TV


CONNECTION TUBE

ES Tubo Conexión DE Verbindungsrohr
IT Tubo connessione PT Tubo de Ligação FR Tube de connexion

● Cad Insertion Point



Ref.	B	L
TV.141650	16	50
TV.141675	16	75



Max. 150°C



6

ACCESSORIES

ACCESSORIES INDEX

ÍNDICE ACCESORIOS / INHALTSVERZEICHNIS ZUBEHÖR
INDICE ACCESSORI / ÍNDICE ACESSÓRIOS / INDEX ACCESSOIRES

154/

Air Valve
Válvula Aire
Luftventil
Valvola Aria
Válvula de Ar
Soupape à Air



154/

Filter Valve
Filtro Válvula
Filterventil
Filtro Valvola
Válvula Filtro
Soupape à Filtre



155/

High Pressure Air Valve
Válvula de Aire para Alta Presión
Luftventil für Hochdruck
Valvola d'Aria per Alte Pressioni
Válvula de Ar para Alta Pressão
Soupape à Air Pour Haute Pression



156/

Double Valve
Válvula Doble
Ventil, Doppelt Wirkend
Valvola Doppia
Válvula Dupla
Double Valve



157/

Sprue Adjuster
Desvío Colada
Angussweiche
Deviazione Colata
Desvío Jito
Régleurs de Carotte



158/

Automatic Safety Strap
Correa de Seguridad Automática
Automatische Sicherheitsverriegelung
Staffa di Sicurezza Automatica
Trinco de Segurança Automático
Bride de Sécurité Automatique



160/

Extension Tube
Tubo Hembra
Verlängerungsrohr
Tubo Prolunga
Tubo de Extensão
Tube à Version



160/

Water Plug for Insert Faces
Tapón Obturador
Verschlussstopfen
Tappo Otturatore
Tampão para Zonas Moldantes
Bouchon Obturateur



161/

Water Connector
Boquilla Refrigeración
Anschlussstück
Bussola Refrigerazione
Record
Raccord de Refroidissement



161/

Cooling Connector
Conector Refrigeración
Kühlung Kuppplungsstück
Attacco Refrigerazione
Conector de Refrigeração
Connexion de Refroidissement



162/

Sprue Bushing Hardened
Casquillo de expulsión de colada templado
Gehärtete Angussbuchse
Boccola di espulsione temprata per canale di colata
Casquilho canal temperado
Douille canal trempé



163/

Seal Bearing
Junta Rotativa
Dichtring
Alimentatore Rotativa
Junta Rotativa
Fontaine Rotative



164/

Seal Bearing
Junta Rotativa
Dichtscheibe
Guarnizione Rotativa
Junta Rotativa
Joint Rotatif



165/

Seal Bearing Tube
Tubo Junta Rotativa
Dichtscheibenrohr
Tubo Alimentatore Rotativo
Tubo Alimentatore Rotativo
Tube Joint Rotatif



165/

Brass Pipe
Tubo Laminado
Messingrohr
Tubo Laminato
Tubo Laminado
Tube Standard



166/

Identification Plate
Placa Identificación
Typenschild
Piastra Identificazione
Placa de Identificação
Plaque d'Identification



167/

Full Color Plate
Placa a Color
Farbige Platten
Piastra a Colori
Placa a Cores
Plaque Selon Couleur



168/

Cable Retainer
Sujeta Cables
Kabelhalter
Piastrina di Cablaggio
Retensor de Cabos
Plaque Blocage Cable



168/

Hose Retainer
Sujeta Tubos
Schlauchhalter
Ferma Cavi
Retensor de Mangueira
Retenu de Tuyau



169/

Interchangeable Wheel
Rueda Recambio
Austauschbare Prägeräder
Ruota di Ricambio
Roda de Substituição
Rondelle de Remplacement



169/

Marking Unit
Unidad de Marcado
Prägestempel
Unità di Marcatura
Unidade de Marcação
Unité de marquage





VA

AIR VALVE

ES Válvula Aire DE Luftventil
IT Valvola Aria PT Válvula de Ar FR Soupape à Air

● Cad Insertion Point

IMPORTANT !
Maximum Injection Pressure: 1200 Kgs/cm² (1BAR ~ 1kg/cm²)



Ref.	A	B	C	D	E	H	M
VA.030312	3	2.6	12	2	2	7	0.7
VA.050412	5	3.4	12	2.1	4	7	2.5
VA.065212	6	5.2	12	1.8	4	7	0.95
VA.086512	8	6.6	12	1.9	6	7	0.95
VA.100812	10	8.2	12	2.7	8	7	0.95
VA.121012	12	9.7	12	2.7	10	7	0.95
VA.161320	16	12.6	20	4	12	12	1.55
VA.201720	20	16.9	20	4	16	12	1.55



IMPORTANT !
Reference VA.030312 and VA.050412, do not include mechanical stop.
La referencia VA.030312 y VA.050412, no incluye tope mecánico.
Referenz VA.030312 und VA.050412 ohne mechanischen Anschlag.
L'articolo VA.030312 e VA.050412 non include freno meccanico.
A referencia VA.030312 e VA.050412 não tem batente mecânico.
La référence VA.030312 et VA.050412 n'inclut pas la butée mécanique.

HIGH PRESSURE AIR VALVE

ES Válvula de Aire para Alta Presión DE Luftventil für Hochdruck
IT Valvola d'Aria per Alte Pressioni PT Válvula de Ar para Alta Pressão FR Soupape à Air Pour Haute Pression

● Cad Insertion Point

IMPORTANT !
Maximum Injection Pressure: 2500 Kgs/cm² (1BAR ~ 1kg/cm²)



Ref.	A	B	D	E	F	H
VH.065215	6	5.4	1.9	4	5.8	0.25
VH.086515	8	6.7	2	5	7.8	0.75
VH.121015	12	9.7	2.7	5	11.8	1

IMPORTANT !
Triple air entrance to ensure balanced opening.
Triple entrada de aire para asegurar una apertura equilibrada.
Dreifacher Lufteinlaß um ein ausgeglichene Öffnung sicherzustellen.
L'ingresso dell'aria è triplo per assicurare un'apertura equilibrata.
Tripla entrada de ar para uma abertura equilibrada.
Triple entrée d'air pour une ouverture équilibrée.

VH

Max. 150°C

Min. 2 BARS
Max. 10 BARS



FV

FILTER VALVE

ES Filtro Válvula DE Filterventil
IT Filtro Valvola PT Válvula Filtro FR Soupape à Filtre

● Cad Insertion Point



IMPORTANT !
Maximum Injection Pressure: 1200 Kgs/cm² (1BAR ~ 1kg/cm²)



Ref.	A	B	C	E
FV.161320	16	13	20	14
FV.201720	20	17	20	18

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




IMPORTANT !
Maximum machining allowed.
Medida máxima de mecanizado.
Maximale Bearbeitung erlaubt.
Quota massima di lavorazione.
Medida máxima a maquina.
Valeur maximum d'usinage.

VD

DOUBLE VALVE

ES Válvula Doble DE Ventil, doppelt wirkend
IT Valvola Doppia PT Válvula Dupla FR Double Valve



● Cad Insertion Point



Ref.	A	B	C	E	H
VD.080512	8	5	12	6	7
VD.100612	10	6	12	8	7
VD.120812	12	8	12	10	7
VD.161020	16	10	20	12	12

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



SPRUE ADJUSTER

ES Desvío Colada DE Angussweiche
IT Deviazione Colata PT Desvio Jito FR Régleurs de Carotte

● Cad Insertion Point



Ref.	A	C	D	E	F	H	J	SW
SA.120014	12	14	4.1	6	3	7	M6	3
SA.160016	16	16	5.1	8	5	8.5	M8	4
SA.200018	20	18	6.1	10	6	11	M10	5
SA.240022	24	22	9.5	12	10	14.5	M14	8




Ref.	A	B	C	D	E	F	H	J	SW
SA.120314	12	3	14	4.1	6	3	7	M6	3
SA.160416	16	4	16	5.1	8	5	8.5	M8	4
SA.200518	20	5	18	6.1	10	6	11	M10	5
SA.240822	24	8	22	9.5	12	10	14.5	M14	8

IMPORTANT !
With ejector bore.
Con alojamiento para expulsor.
Mit Auswerferbohrung.
Con alloggiamento per espulsore.
Com alojamento para extractor.
Avec placement pour l'éjecteur.

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

Trapezoidal runner Full round runner



Possible configurations

Posibles Aplicaciones · Einsatzmöglichkeiten · Possibili Applicazioni · Possíveis Aplicações · Possibilités d'Application



SA

Patented
Max. 100°C

AUTOMATIC SAFETY STRAP

ES Brida de Seguridad Automática DE Automatische Sicherheitsverriegelung
IT Staffa di Sicurezza Automatica PT Trinco de Segurança Automático FR Bride de sécurité automatique

INSTALLATION GUIDELINES

ES Consejos de Instalación DE Richtlinien zur Installation
IT Consigli di Installazione PT Instruções de Instalação FR Mode d'Installation



AS


AS

ACCESSORIES

ACCESSORIES

Max. 150°C

Max. 150°C




Core Housing

Alojamiento Placa Punzón · Einbaumaße PB Führung · Sede nel Punzone · Alojamento Bucha · Logement dans l'empreinte


Cavity Housing

Alojamiento Placa Cavidad · Einbaumaße DR Führung · Sede piastra cavità · Alojamento na Cavidade · Logement dans l'empreinte





Ref.	A	B	C	D	E	F	G	H	I	J	K	L	M	N	P	Q	R	S	T	T2	U	V	W	X	Y	Z	SW	Max. Mold Size
AS.462024	46	20	25	21	26	70	190	39	100	16	619	24	30	43.8	20.8	18	12.3	M12x60	M8x50	31.8	12.3	35	15	35	55	10	10Tons	
AS.582430	58	24	30	25	36	90	220	45	120	20	644	30	54	56	24	36	17	M16x70	M10x50	40	17	40	18	43.5	69	14	20Tons	
AS.764040	76	40	40	32	42	100	260	48	152	24	674	32	60	68	40	34	18	M16x90	M10x50	56	25.2	50	26	60	85	14	30Tons	

WAREHOUSE



PRODUCTION




TH



EXTENSION TUBE

ES Tubo Hembra DE Verlängerungsrohr
IT Tubo Prolunga PT Tubo de Extensão FR Tube à Version

● Cad Insertion Point



Max. 150°C


IMPORTANT
Indicate the desired **L** dimension after the reference.
Indicar la cota **L** necesaria después de la referencia.
Gewünschte Länge **L** angeben.
Indicare la quota **L** desiderata dopo il codice.
Indique a dimensão **L** desejada depois da referência.
Indiquer longueur (**L**) désirée après référence.

Ref.	A	B	C	R	L				SW	
TH.181005-...	1/8"	10	9.5	1/8"	50	75	100	125	-	5
TH.141408-...	1/4"	14	11.5	1/4"	50	75	100	125	150	8

WATER PLUG FOR INSERT FACES

ES Tapón Obturador DE Verschlussstopfen
IT Tappo Otturatore PT Tampão para Zonas Moldantes FR Bouchon Obturateur

● Cad Insertion Point




Ref.	A	B	C	D
T0.061063	6	10	6.3	5.9
T0.081284	8	12	8.4	7.9
T0.101410	10	14	10.5	9.9
T0.151615	15	16	15.5	14.9

Max. 150°C

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



WATER CONNECTOR

ES Boquilla Refrigeración DE Anschlussstück
IT Bussola Refrigerazione PT Record FR Raccord de Refroidissement

● Cad Insertion Point



BR




Ref.	A	B	C	D	E	F
BR.10E0C5	G M10	7	24	11	5	9
BR.18E0C5	G 1/8"	7	24	11	5	9
BR.14E0C5	G 1/4"	9	26	15	5	9
BR.14E0C8	G 1/4"	9	26	15	8	13.5
BR.38E0C8	G 3/8"	9	26	15	8	13.5

European System

Max. 150°C

Installation Guidelines


Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



COOLING CONNECTOR

ES Conector Refrigeración DE Kühlung Kupplungsstück
IT Attacco Refrigerazione PT Conector de Refrigeração FR Connexion de Refroidissement

● Cad Insertion Point




Ref.
RL.181235

RL



Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Max. 80°C

SPRUE BUSHING HARDENED


ES Casquillo de expulsión de colada templado DE Gehärtete Angussbuchse
IT Boccola di espulsione temprata per canale di colata PT Casquillo canal temperado FR Douille canal trempé

EC


SERIE 51110



STANDARD




CONICAL



STANDARD	CONICAL	D2	F	L3	D3	L1	D1
S51110-20-12-60-6	CS51110-20-12-60-6	16	6	20	12	60	6
S51110-26-14-xxx-8	CS51110-26-14-xxx-8	20	7	26	14	80	8
S51110-26-16-xxx-10	CS51110-26-16-xxx-10	22	8	26	16	80	10
S51110-50-14-120-8	CS51110-50-14-120-8	20	7	50	14	120	8
S51110-50-16-120-10	CS51110-50-16-120-10	22	8	50	16	120	10

IMPORTANT
Replace the **xxx** in the reference with the L1 dimension.
Sustituir la **xxx** de la referencia por la cota L1.
Ersetzen Sie bei der Referenz das **xxx** durch die gewünschte L1 Dimension.
Sostituite la **xxx** del codice con la dimensione L1.
Substituir o **xxx** da referencia pela cota L1.
Remplacez la valeur **xxx** par la valeur L1.


SERIE 51011



STANDARD



CONICAL



STANDARD	CONICAL	D2	F	D3	L1	D1
S51011-10-80-6	CS51011-10-80-6	16	5	10	80	6
S51011-12-80-8	CS51011-12-80-8	18	6	12	80	8
S51011-14-xxx-8	CS51011-14-xxx-8	20	7	14	80	8
S51011-16-xxx-10	CS51011-16-xxx-10	22	8	16	80	10


IMPORTANT
Replace the **xxx** in the reference with the L1 dimension.
Sustituir la **xxx** de la referencia por la cota L1.
Ersetzen Sie bei der Referenz das **xxx** durch die gewünschte L1 Dimension.
Sostituite la **xxx** del codice con la dimensione L1.
Substituir o **xxx** da referencia pela cota L1.
Remplacez la valeur **xxx** par la valeur L1.

SEAL BEARING

ES Junta Rotativa DE Dichtring
IT Alimentatore Rotativa PT Junta Rotativa FR Fontaine Rotative

JR

● Cad Insertion Point




Ref.	A	B	C	D	E	F	G	H	J	K	S
JR.061226	6	12	26	24	8	13	21	8.5	13	26	5
JR.081529	8	15	29.5	32	8	17	21	10.5	13	35	7
JR.101942	10	19	42	39	8	21	21	14	13	41	9
JR.122245	12	22	45	42	10	26	23	17	13	45	11
JR.162550	16	25	50	47	10	27	24	22	14	50	15

IMPORTANT
Every seal must have a separate exit, do not connect in-line. Do not dry-run the parts.
Cada junta debe tener una salida diferente, no conectar en linea. No trabajar en seco.
Nicht in Reihe verbinden, jedes Teil benötigt einen separaten Ausgang. Die JR Dichtung nicht trocken laufen lassen.
Ogni figura deve avere un proprio foro di refrigerazione, non bisogna collegare i fori in linea. Non usare a secco.
Cada junta deve ter uma saída individual, não ligar em serie. Não utilizar a seco.
Chaque circuit doit être indépendant et non raccordé en série. Ne pas utiliser à sec.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




SB



SEAL BEARING

ES Junta Rotativa DE Dichtscheibe
IT Guarnizione Rotativa PT Junta Rotativa FR Joint Rotatif




● Cad Insertion Point



Ref.	A	B	C	D	E
SB.143234	14	32	34	36	18
SB.183638	18	36	38	40	22
SB.254446	25	44	46	48	30
SB.325254	32	52	54	56	36

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




IMPORTANT Use only grease or oil without solid additives.
Usar solamente aceites o grasas sin aditivos sólidos.
Verwenden Sie nur Fett oder Öl ohne Beimischung von Feststoffen.
Usare esclusivamente olii o grassi senza additivi solidi.
Usar apenas lubrificantes sem aditivos sólidos.
Seulement utiliser avec huile ou graisse sans additifs solide.

SEAL BEARING TUBE

ES Tubo Junta Rotativa DE Dichtscheibenrohr
IT Tubo Alimentatore Rotativo PT Tubo Junta Rotativa FR Tube Joint Rotatif

● Cad Insertion Point




Ref.	E	F	G
TB.061230	6	12	4
TB.081430	8	14	6
TB.101630	10	16	8
TB.122030	12	20	10

BRASS PIPE

ES Tubo Laminado DE Messingrohr
IT Tubo Laminato PT Tubo Laminado FR Tube Standard

● Cad Insertion Point



Ref.	M	N
TL.040620	4	6
TL.060820	6	8
TL.081020	8	10
TL.101220	10	12

TB

Patented

Max. 80°C


TL

Max. 150°C

PI

IDENTIFICATION PLATE


ES Placa Identificación DE Typenschild
IT Piastra Identificazione PT Placa de Identificação FR Plaque d'Identification



● Cad Insertion Point

10x10 Free graphic area

Black Anodized Aluminium



Ref.	Drawing	A	B	C	D
PI.068345	PI.068345-DW	68	34	59	25
PI.090455	PI.090455-DW	90	45	81	36
PI.120605	PI.120605-DW	120	60	111	51
PI.160805	PI.160805-DW	160	80	151	71

How to order this part?

Cómo realizar un pedido? · Bestellvorgang · Come realizzare un ordine? · Como realizar um pedido? · Comment effectuer une commande?

- DESIGN.** The DXF and PDF vectorized file containing the required design must be sent by email.
ES DISEÑO. Nos envían por e-mail un archivo en formato DXF y PDF vectorizado que contenga el diseño a grabar.
DE ENTWURF. Die vektorisierte DXF und PDF-Datei, die das gewünschte Design enthält, muss per E-Mail gesendet werden.
IT DISEGNO. Inviateci via e-mail un archivo in formato DXF e PDF vettoriale che contenga il disegno da incidere.
PT DESENHO. Enviar por e-mail um arquivo em formato DXF e PDF vectorizado que contenha o desenho a gravar.
FR CONCEPTION. Envoyer par e-mail un fichier au format DXF et PDF vectorisé contenant la conception de la plaque à graver.


- DELIVERY:** Unless otherwise advised, the model "TEXT" plates will be finished in 48 hours and the model "DRAWING" in 72 hours, both cases upon customer order confirmation.
ES REALIZACION: Salvo indicación contraria, las placas del modelo "TEXT" (Texto) estarán finalizadas en 48 horas y las del modelo "DRAWING" (Dibujo) en 72 horas, en ambos casos después de la confirmación del pedido por parte del cliente.
DE LIEFERUNG: Wenn es keine vorgeschriebenen Termine gibt, die Ausführung als "TEXT" ist fertig zur Auslieferung nach 48 Std., die Ausführung als "DRAWING" (Zeichnung) nach 72 Std, jeweils nach erteilter Auftragsbestätigung.
IT REALIZZAZIONE: salvo indicazione contraria, le placchette del modello TEXT saranno terminate in 48 ore e quelle del modello DRAWING in 72 ore, in entrambi i casi solo dopo la conferma dell'ordine da parte del cliente.
PT PRAZO DE ENTREGA: Salvo indicação contrária, as placas de modelo "TEXT" serão entregues num prazo máximo de 48h e as de modelo "DRAWING" em 72 horas, em ambos os casos, depois da confirmação de encomenda por parte do cliente.
FR RÉALISATION : Sauf indication contraire, les plaques du modèle «TEXT » (Texte) seront réalisées dans les 48 heures et celles du modèle « DRAWING » (Dessin) dans les 72 heures, dans les deux cas, il faudra la validation de la commande par le client.

FULL COLOR PLATE


ES Placas a Color DE Farbige Platten
IT Piastra a Colori PT Placa Totalmente a Cores FR Plaquettes Selon Couleur



CP



M4x12
4xDIN7984



Ref.	Max. A	Max. B
CP.050070	70	50
CP.060100	100	60
CP.070120	120	70
CP.080160	160	80
CP.100200	200	100
CP.140200	200	140
CP.200200	200	200
CP.200285	285	200
CP.280370	370	280

How to order this part?

Cómo realizar un pedido? · Bestellvorgang · Come realizzare un ordine? · Como realizar um pedido? · Comment effectuer une commande?


- Send a PDF file with the following properties:**
 - Send desired design at 1:1 Scale.
 - Provide drawing inside of a rectangle with the correct plate dimensions.
 - Do not draw the screw holes neither the rounded corners.
 - Unless otherwise advised, the plaque will be finished in 48-72 hours, after customer order confirmation.**

ES Salvo indicación contraria, las placas estarán disponibles en 48-72 horas después de la confirmación del cliente.
DE Soweit nichts anderes angegeben ist, werden die Platten innerhalb von 48-72 Stunden nach Auftragsbestätigung gefertigt.
IT Salvo avvisi contrari, la produzione dura 48-72h dalla conferma d'ordine del cliente.
PT As placas estarão prontas em 48-72 após confirmação, salvo indicação em contrário.
FR Les plaquettes seront prêtes en 48-72h après confirmation, sauf indication contraire.
- ES Enviar un archivo PDF con las características:**
- El diseño deseado y escala 1:1
 - Delimitado por un rectángulo con la medida de la placa.
 - Sin cantos redondeados ni agujeros.
- DE Senden Sie eine PDF-Datei mit den folgenden Merkmalen an uns:**
- Der gewünschte Entwurf im Maßstab 1:1.
 - Stellen Sie uns eine Zeichnung innerhalb eines Rechtecks mit den korrekten Plattenabmessungen zur Verfügung.
 - Zeichnen Sie weder die Schraubenlöcher noch die abgerundeten Ecken ein.
- IT Inviare un file PDF con queste caratteristiche:**
- Il disegno desiderato e la scala 1:1
 - Delimitato da un rettangolo con le dimensioni della piastra
 - Senza bordi arrotondati o fori.
- PT Enviar ficheiro PDF com as seguintes características:**
- O desenho pretendido na escala de 1:1
 - Delimitado por um retângulo com a medida da chapa.
 - Sem cantos em raio nem furos.
- FR Envoyez le fichier PDF avec les caractéristiques suivantes:**
- Plan à l'échelle 1 : 1
 - Sous forme de rectangle avec les dimensions réelles de la plaque.
 - Sans rayons , ni passage de vis.


SC

CABLE RETAINER

ES Sujeta Cables DE Kabelhalter
IT Piastrina di Cablaggio PT Retensor de Cabos FR Plaque Blocage Cable





Ref.	A	B	Material	Max. Temp.
SC.401245	40	28	Nylon	80°C
SC.401245H	40	28	PA+30% Glass Fiber	150°C
SC.601245	60	48	Nylon	80°C
SC.601245H	60	48	PA+30% Glass Fiber	150°C



IMPORTANT ! Supplied in bags of 10 units.
Suministrado en bolsas de 10 uds.
Verpackungseinheit 10 Stück.
Vendute in confezioni da 10 pezzi.
Fornecidos em sacos de 10 unidades.
Emballé en sac de 10 unités.

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation




Max. 150°C



MARKING UNIT

ES Unidad de Marcado DE Prägestempel
IT Unità di Marcatatura PT Unidade de Marcação FR Unité de Marquage


● Cad Insertion Point



! A = N° of wheels



Ref.	A	B	C
UM.043642	4	36	22
UM.064242	6	42	28



UM

Patented


Max. 150°C

SM

HOSE RETAINER

ES Sujeta Tubos DE Schlauchhalter
IT Ferma Cavi PT Retensor de Mangueira FR Retenu de Tuyau


● Cad Insertion Point



Ref.
SM.122020

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation





Max. 80°C

INTERCHANGEABLE WHEEL

ES Rueda Recambio DE Austauschbare Prägeräder
IT Ruota di Ricambio PT Roda de Substituição FR Rondelle de Remplacement

Ref.
RR.180311



RR

Patented

Max. 150°C

**INNOVATING
FOR YOUR
MOLDS**